



OPERATORS MANUAL MARINE DIESEL GENERATORS


SINGLE AND THREE PHASE

8.0 - 60Hz ___ 6.0 - 50Hz BTD

10.0 - 60Hz ___ 7.5 - 50Hz BTD

11.0 - 60Hz ___ 8.8 - 50Hz BTD

12.5 - 60Hz ___ 9.4 - 50Hz BTD(A)



PUBLICATION NO: 36746 / REV. 5 - JULY 2018



WESTERBEKE CORPORATION • 150 JOHN HANCOCK ROAD
MYLES STANDISH INDUSTRIAL PARK • TAUNTON MA 02780
WEBSITE: WWW.WESTERBEKE.COM

**CALIFORNIA
PROPOSITION 65 WARNING**


Marine diesel and gasoline engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

⚠ WARNING

Exhaust gasses contain Carbon Monoxide, an odorless and colorless gas. Carbon Monoxide is poisonous and can cause unconsciousness and death. Symptoms of Carbon Monoxide exposure can include:

- **Dizziness**
- **Nausea**
- **Headache**
- **Weakness and Sleepiness**
- **Throbbing in Temples**
- **Muscular Twitching**
- **Vomiting**
- **Inability to Think Coherently**

IF YOU OR ANYONE ELSE EXPERIENCE ANY OF THESE SYMPTOMS, GET OUT INTO THE FRESH AIR IMMEDIATELY. If symptoms persist, seek medical attention. Shut down the unit and do not restart until it has been inspected and repaired.



A WARNING DECAL is provided by WESTERBEKE and should be fixed to a bulkhead near your engine or generator.

WESTERBEKE also recommends installing CARBON MONOXIDE DETECTORS near the engine room. They are inexpensive and easily obtainable at your local hardware store.

SAFETY INSTRUCTIONS

INTRODUCTION

Read this safety manual carefully. Most accidents are caused by failure to follow fundamental rules and precautions. Know when dangerous conditions exist and take the necessary precautions to protect yourself, your personnel, and your machinery.

As the owner or operator, always observe the following safety rules and advisories provided for your convenience. This safety information is in alignment with the American Boat and Yacht Council (ABYC) standards; however, safety risks are not limited to the information in the following pages. The responsibility for the identification of potential and actual risks for compliance with all safety advisories, maintenance activities, and other conditions belong exclusively to the owner/operator.

PREVENT ELECTRIC SHOCK

⚠ WARNING: Do not touch AC electrical connections while engine is running, or when connected to shore power. Lethal voltage is present at these connections!

- Do not operate this machinery without electrical enclosures and covers in place.
- Shut off electrical power before accessing electrical equipment.
- Use insulated mats whenever working on electrical equipment.
- Make sure your clothing and skin are dry, not damp (particularly shoes) when handling electrical equipment.
- Remove wristwatch and all jewelry when working on electrical equipment.

PREVENT BURNS — HOT ENGINE

⚠ WARNING: Do not touch hot engine parts or exhaust system components. A running engine gets very hot!

- Monitor engine antifreeze coolant level at the plastic coolant recovery tank and periodically at the filler cap location on the water jacketed exhaust manifold, but only when the engine is COLD.

⚠ WARNING: Steam can cause injury or death!

- In case of an engine overheat, allow the engine to cool before touching the engine or checking the coolant.

PREVENT BURNS — FIRE

⚠ WARNING: Fire can cause injury or death!

- Prevent flash fires. Do not smoke or permit flames or sparks to occur near the carburetor, fuel line, filter, fuel pump, or other potential sources of spilled fuel or fuel vapors. Use a suitable container to catch all fuel when removing the fuel line, carburetor, or fuel filters.
- Do not operate with the air cleaner/silencer removed. Backfire can cause severe injury or death.
- Do not smoke or permit flames or sparks to occur near the fuel system. Keep the compartment and the engine/generator clean and free of debris to minimize the chances of fire. Wipe up all spilled fuel and engine oil.
- Be aware — diesel fuel will burn.

PREVENT BURNS — EXPLOSION

⚠ WARNING: Explosions from fuel vapors can cause injury or death!

- Follow re-fueling safety instructions. Keep the vessel's hatches closed when fueling. Open and ventilate cabin after fueling. Check below for fumes/vapor before running the blower. Run the engine compartment blower prior to starting, following the recommendation of the vessel builder.
- All fuel vapors are highly explosive. Use extreme care when handling and storing fuels. Store fuel in a well-ventilated area away from spark-producing equipment and out of the reach of children.
- Do not fill the fuel tank(s) while the engine is running.
- Shut off the fuel service valve at the engine when servicing the fuel system. Take care in catching any fuel that might spill. DO NOT allow any smoking, open flames, or other sources of fire near the fuel system or engine when servicing. Ensure proper ventilation exists when servicing the fuel system.
- Do not alter or modify the fuel system.
- Be sure all fuel supplies have a positive shutoff valve.
- Be certain fuel line fittings are adequately tightened and free of leaks.
- Make sure a fire extinguisher is installed nearby and is properly maintained. Be familiar with its proper use. Extinguishers rated ABC by the NFPA are appropriate for all applications encountered in this environment.

SAFETY INSTRUCTIONS

ACCIDENTAL STARTING

⚠ WARNING: Accidental starting can cause injury or death!

- Disconnect the battery cables before servicing the engine/generator. Remove the negative lead first and reconnect it last.
- Make certain all personnel are clear of the engine before starting.
- Make certain all covers, guards, and hatches are re-installed before starting the engine.

BATTERY EXPLOSION

⚠ WARNING: Battery explosion can cause injury or death!

- Do not smoke or allow an open flame near the battery being serviced. Lead acid batteries emit hydrogen, a highly explosive gas, which can be ignited by electrical arcing or by lit tobacco products. Shut off all electrical equipment in the vicinity to prevent electrical arcing during servicing.
- Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together. Sparks could ignite battery gases or fuel vapors. Ventilate any compartment containing batteries to prevent accumulation of explosive gases. To avoid sparks, do not disturb the battery charger connections while the battery is being charged.
- Avoid contacting the terminals with tools, etc., to prevent burns or sparks that could cause an explosion. Remove wristwatch, rings, and any other jewelry before handling the battery.
- Always turn the battery charger off before disconnecting the battery connections. Remove the negative lead first and reconnect it last when servicing the battery.

BATTERY ACID

⚠ WARNING: Sulfuric acid in batteries can cause severe injury or death!

- When servicing the battery or checking the electrolyte level, wear rubber gloves, a rubber apron, and eye protection. Batteries contain sulfuric acid which is destructive. If it comes in contact with your skin, wash it off at once with water. Acid may splash on the skin or into the eyes inadvertently when removing electrolyte caps.

TOXIC EXHAUST GASES

⚠ WARNING: Carbon monoxide (CO) is a deadly gas!

- Ensure that the exhaust system is adequate to expel gases discharged from the engine. Check the exhaust system regularly for leaks and make sure the exhaust manifold/water-injected elbow is securely attached.
- Be sure the unit and its surroundings are well ventilated. Run blowers when running the generator set or engine.
- Do not run the generator set or engine unless the boat is equipped with a functioning marine carbon monoxide detector that complies with ABYC A-24. Consult your boat builder or dealer for installation of approved detectors.
- For additional information, refer to ABYC TH-22 (educational information on Carbon Monoxide).

⚠ WARNING: Carbon monoxide (CO) is an invisible odorless gas. Inhalation produces flu-like symptoms, nausea or death!

- Do not use copper tubing in diesel exhaust systems. Diesel fumes can rapidly destroy copper tubing in exhaust systems. Exhaust sulfur causes rapid deterioration of copper tubing resulting in exhaust/water leakage.
- Do not install exhaust outlet where exhaust can be drawn through portholes, vents, or air conditioners. If the engine exhaust discharge outlet is near the waterline, water could enter the exhaust discharge outlet and close or restrict the flow of exhaust. Avoid overloading the craft.
- Although diesel engine exhaust gases are not as toxic as exhaust fumes from gasoline engines, carbon monoxide gas is present in diesel exhaust fumes. Some of the symptoms or signs of carbon monoxide inhalation or poisoning are:
 - Vomiting
 - Dizziness
 - Headache
 - Nausea
 - Inability to think coherently
 - Throbbing in temples
 - Muscular twitching
 - Weakness and sleepiness

AVOID MOVING PARTS

⚠ WARNING: Rotating parts can cause injury or death!

- Do not service the engine while it is running. If a situation arises in which it is absolutely necessary to make operating adjustments, use extreme care to avoid touching moving parts and hot exhaust system components.

SAFETY INSTRUCTIONS

- Do not wear loose clothing or jewelry when servicing equipment; avoid wearing loose jackets, shirts, sleeves, rings, necklaces or bracelets that could be caught in moving parts.
- Make sure all attaching hardware is properly tightened. Keep protective shields and guards in their respective places at all times.
- Do not check fluid levels or the drive belt's tension while the engine is operating.
- Stay clear of the drive shaft and the transmission coupling when the engine is running; hair and clothing can easily be caught in these rotating parts.

HAZARDOUS NOISE

 **WARNING:** *High noise levels can cause hearing loss!*

- Never operate an engine without its muffler installed.
- Do not run an engine with the air intake (silencer) removed.

 **WARNING:** *Do not work on machinery when you are mentally or physically incapacitated by fatigue!*

OPERATORS MANUAL

Many of the preceding safety tips and warnings are repeated in your Operators Manual along with other cautions and notes to highlight critical information. Read your manual carefully, maintain your equipment, and follow all safety procedures.

ENGINE AND GENERATOR INSTALLATIONS

Preparations to install an engine should begin with a thorough examination of the American Boat and Yacht Council's (ABYC) standards. These standards are a combination of sources including the USCG and the NFPA.

Sections of the ABYC standards of particular interest are:

- H-32 Ventilation for boats using diesel fuel
- H-33 Diesel Fuel Systems
- P-1 Installation of Exhaust Systems for Propulsion and Auxiliary Engines
- P-4 Marine Inboard Engines and Transmissions
- E-11 AC & DC Electrical Systems on Boats
- TA Batteries and Battery Chargers

All installations must comply with the Federal Code of Regulations (FCR).

ABYC, NFPA AND USCG PUBLICATIONS FOR INSTALLING MARINE ENGINES AND GENERATORS

Read the following ABYC, NFPA and USCG publications for safety codes and standards. Follow their recommendations when installing your UNIVERSAL engine

ABYC (American Boat and Yacht Council)
"Safety Standards for Small Craft"

Order From:

ABYC
613 Third Street, Suite 10
Annapolis, MD 21403
(410) 990-4460
www.abycinc.org

NFPA (National Fire Protection Association)
"Fire Protection Standard for Motor Craft"

Order From:

NFPA
1 Batterymarch Park
P.O. Box 9101
Quincy, MA 02269-9101

USCG (United States Coast Guard)
"CFR 33 AND CFR46"
Code of Federal Regulations

Order From:

U.S. Government Printing Office
Washington, D.C. 20404

INSTALLATION

When installing WESTERBEKE engines and generators it is important that strict attention be paid to the following information:

CODES AND REGULATIONS


Strict federal regulations, ABYC guidelines, and safety codes must be complied with when installing engines and generators in a marine environment.

SIPHON-BREAK

For installations where the exhaust manifold/water injected exhaust elbow is close to or will be below the vessel's waterline, provisions must be made to install a siphon-break in the raw water supply hose to the exhaust elbow. This hose must be looped a minimum of 20" above the vessel's waterline. *Failure to use a siphon-break when the exhaust manifold injection port is at or below the load waterline will result in raw water damage to the engine and possible flooding of the boat.*

If you have any doubt about the position of the water-injected exhaust elbow relative to the vessel's waterline under the vessel's various operating conditions, *install a siphon-break.*

NOTE: *A siphon-break requires periodic inspection and clearing to ensure proper operation. Failure to properly maintain a siphon-break can result in catastrophic engine damage. Consult the siphon-break manufacturer for proper maintenance.*



AVAILABLE FROM
YOUR WESTERBEKE
DEALER

SIPHON-BREAK WITH STAINLESS
LOOP

EXHAUST SYSTEM

The exhaust system's hose **MUST** be certified for marine use. Corrugated Marine Exhaust Hose is recommended. The use of this type of hose allows for extreme bends and turns without the need of additional fitting and clamps to accomplish these bends and turns. In this regard, a single length of corrugated exhaust hose can be used. The system **MUST** be designed to prevent the entry of water into the exhaust system under any sea conditions and at any angle of vessels heel.



A detailed Marine Installation Manual covering gasoline and diesel, engines and generators, is supplied with each unit. A pdf is available to download from our website at www.westerbeke.com.

TABLE OF CONTENTS

Parts Identification	2	Specifications	
Introduction	3	8.0 Kw BTD	28
Diesel Fuel, Engine Oil and Engine Coolant	5	10.0 Kw BTD	30
Generator Control Panels	6	11.0 Kw BTD	32
Preparations for Initial Start-Up	7	12.5 Kw BTD(A).....	34
Safety Shutdown Switches and Sensors	8	BT Generator 6 and 12 Stud	37
Starting/Stopping Procedure	9	Voltage Regulator	38
Generator Break-In Procedure	10	BT Troubleshooting Chart.....	38
Maintenance Schedule	11	Internal Wiring Schematic (12 Stud)	39
Cooling System	13	Resistance Values	39
Raw Water Pumps	14	Generator Voltage Adjustment	40
Intake Strainer	14	No Load	40
Heat Exchanger	14	Full Load	40
Thermostat	15	Generator Frequency	41
Zinc Anode	16	6 Stud AC Connections	41
Air Intake Silencer	16	Internal Wiring Schematic (6 Stud)	42
Fuel System	17	Resistance Values	42
Fuel Filters.....	17	Internal Wiring Diagram	
Fuel Lift Pump.....	18	3 Phase, 12 Wire, Reconnectable	43
Engine Lubricating Oil	19	AC Voltage Connections BE 3 Phase	44
Oil Change.....	19	Shore Power Transfer Switch	45
Oil Pressure	19	Wiring Diagrams	
DC Electrical System	20	#34651 - 8 BT	46
Alternator.....	20	#36412 - No Relays.....	47
Starter Motor	22	#36412 - Schematic No Relays	48
Testing	22	#36412 - Two Relays.....	49
Disassembly.....	23	#36412 - Schematic Two Relays.....	50
Engine Adjustments	24	#41479 - BTDA and BTDA(A)	51
Glow Plugs	24	#41479 - Schematic	52
Injector.....	24	#43853 - BTDA and BTDA	53
Throttle Control/Generator Frequency	25	#43853 - Schematic	54
Drive Belt Adjustment.....	25	#43944 - BTDA Diagram.....	55
Valve Clearance and Timing	26	#43944 - BTDA Schematic	56
11.0 BTDA and 12.5 BTDA(A).....	26	Remote Oil Fill	57
8.0 and 10.0 BTDA	27	Power Take Off System	58
		Lay-Up and Recommissioning	59
		Suggested Spare Parts	61

PARTS IDENTIFICATION / ALL MODELS

The Control Panel faces aft on some of these models with the emergency Stop Switch on the back.



INTRODUCTION

This WESTERBEKE Diesel Generator is a product of WESTERBEKE's long years of experience and advanced technology. We take great pride in the superior durability and dependable performance of our engines and generators. Thank you for selecting WESTERBEKE.

In order to get the full use and benefit from your generator it is important that you operate and maintain it correctly. This manual is designed to help you do this. Please, read this manual carefully and observe all the safety precautions throughout. Should your generator require servicing, contact your nearest WESTERBEKE dealer for assistance.

This is your operators manual. Along with this manual, there is an Installation Manual and Parts Information. A Service Manual is available in pdf form on our website or can be ordered in book form from a WESTERBEKE/UNIVERSAL Dealer

WARRANTY PROCEDURES

Your WESTERBEKE Warranty Statement is included in the product documentation package. There is a Warranty Registration Card you can fill out and mail to Westerbeke Corporation or go to our website: www.westerbeke.com and register your products warranty on line. You should receive a Customer Identification card in the mail within 60 days of registering. If you do not, please contact the factory and have your product model number, serial number and in service date available.

Customer Identification Card

	
Customer Identification	
MR. GENERATOR OWNER	
MAIN STREET	
HOMETOWN, USA	
Model _____	Serial # _____
Expires _____	

NOTES, CAUTIONS AND WARNINGS

As this manual takes you through the operating procedures, maintenance schedules, and troubleshooting of your marine engine, critical information will be highlighted by NOTES, CAUTIONS, and WARNINGS. An explanation follows:

NOTE: An operating procedure essential to note.

CAUTION: Procedures, which if not strictly observed, can result in the damage or destruction of your engine.

WARNING: Procedures, which if not properly followed, can result in personal injury or loss of life.

PRODUCT SOFTWARE

Product software, (tech data, parts lists, manuals, brochures and catalogs), provided from sources other than WESTERBEKE are not within WESTERBEKE's control.

WESTERBEKE CANNOT BE RESPONSIBLE FOR THE CONTENT OF SUCH SOFTWARE, MAKES NO WARRANTIES OR REPRESENTATIONS WITH RESPECT THERETO, INCLUDING ACCURACY, TIMELINESS OR COMPLETENESS THEREOF AND WILL IN NO EVENT BE LIABLE FOR ANY TYPE OF DAMAGE OR INJURY INCURRED IN CONNECTION WITH OR ARISING OUT OF THE FURNISHING OR USE OF SUCH SOFTWARE.

WESTERBEKE customers should also keep in mind the time span between printings of WESTERBEKE product software and the unavoidable existence of earlier WESTERBEKE manuals. In summation, product software provided with WESTERBEKE products, whether from WESTERBEKE or other suppliers, must not and cannot be relied upon exclusively as the definitive authority on the respective product. It not only makes good sense but is imperative that appropriate representatives of WESTERBEKE or the supplier in question be consulted to determine the accuracy and currentness of the product software being consulted by the customer.

PROTECTING YOUR INVESTMENT

Care at the factory during assembly and thorough testing have resulted in a WESTERBEKE generator capable of many thousands of hours of dependable service. However the manufacturer cannot control how or where the generator is installed in the vessel or the manner in which the unit is operated and serviced in the field. This is up to the buyer/owner-operator.

NOTE: Six important steps to ensure long generator life:

- Proper engine and generator installation and alignment.
- An efficient well-designed exhaust system that includes an anti-siphon break to prevent water from entering the engine.
- Changing the engine oil and oil filters according to the maintenance schedule.
- Proper maintenance of all engine and generator components according to the maintenance schedule in this manual.
- Use clean, filtered #2 diesel fuel.
- Winterize your engine according to the "Lay-up and Recommissioning" section in this manual.

INTRODUCTION

SERIAL NUMBER LOCATION

The engine's model and serial number are located on a nameplate mounted on the side of the water jacketed exhaust manifold.

The engine's serial number is also found stamped in the engine block on a flat surface just above the side oil fill opening. Take time to enter this information below on the illustrated nameplate.

SPECIFICATION	50 HZ.	60 HZ.
MODEL		
RPM		
KW		
KVA		
VOLTS		
AMPS		
ENG. HP		
ENG. SER. NO.		
GEN. SER. NO.		
PF/PHASE	/	
WIRES		
RATING		
INSUL. CLASS		
TEMP. RISE		
BATTERY		
C.I.D.		



An identification plate on the top of the engine air intake also displays the engine model and serial number.

CARBON MONOXIDE DETECTOR

WESTERBEKE recommends mounting a carbon monoxide detector in the vessels living quarters. Carbon monoxide, even in small amounts, is deadly.

The presence of carbon monoxide indicates an exhaust leak from the engine or generator or from the exhaust elbow/exhaust hose, or the fumes from a nearby vessel are entering your boat.

If carbon monoxide is present, ventilate the area with clean air and correct the problem immediately!

NOTE: A carbon monoxide warning decal has been provided by WESTERBEKE. Affix this decal in a visible position in the engine room.

UNDERSTANDING THE DIESEL ENGINE

The diesel engine closely resembles the gasoline engine, since the mechanism is essentially the same. The cylinders are arranged above a closed crankcase; the crankshaft is of the same general type as that of a gasoline engine; and the diesel engine has the same types of valves, camshaft, pistons, connecting rods and lubricating system.

Therefore, to a great extent, a diesel engine requires the same preventive maintenance as a gasoline engine. The most important factors are proper ventilation and proper maintenance of the fuel, lubricating and cooling systems. Replacement of fuel and lubricating filter elements at the time periods specified is a must, and frequent checking for contamination (that is, water, sediment, etc.) in the fuel system is also essential. Another important factor is the use of the same brand of high detergent diesel lubrication oil designed specifically for diesel engines.

The diesel engine does differ from the gasoline engine, however, in its method of handling and firing of fuel. The carburetor and ignition systems are done away with and in their place is a single component – the fuel injection pump – which performs the function of both.

ORDERING PARTS


Whenever replacement/service parts are needed, always provide the generator model number, engine serial number, and generator serial number as they appear on the silver and black name plate located on the generator end. You must provide us with this information so we may properly identify your generator set. In addition, include a complete part description and part number for each part needed (see the separately furnished Parts List). Also insist upon WESTERBEKE packaged parts because *will fit* or generic parts are frequently not made to the same specifications as original equipment.

SPARES AND ACCESSORIES

Certain spares will be needed to support and maintain your WESTERBEKE generator. Your local WESTERBEKE dealer will assist you in preparing an inventory of spare parts. See the *SPARE PARTS* page in this manual. For Engine and Generator Accessories, see the *ACCESSORIES* brochure.

INSTALLATION MANUAL

The Westerbeke Installation Manual publication #043268 is supplied with this unit.



DIESEL FUEL, ENGINE OIL AND ENGINE COOLANT

DIESEL FUEL

Use a diesel fuel that meets the requirements of No. 2-D SAE J 313 and has a Cetane rating of #45 or higher grade of diesel fuel according to ASTM D975.

Care Of The Fuel Supply

Use only clean diesel fuel! The clearance of the components in your engines fuel injection pump is very critical; invisible dirt particles which might pass through the primary and secondary filters can damage these finely machined parts. It is important to buy clean fuel, and keep it clean. The best fuel can be rendered unsatisfactory by careless handling or improper storage facilities. To assure that the fuel going into the tank for your engine's daily use is clean and pure, the following practice is advisable:

Purchase a well-known brand of fuel. The use of additives to combat BACTERIAL growth on the fuel tank is recommended such as Bio-Bor and an additive such as *Diesel Kleen + Cetane Boost* to help restore lubricity back into the diesel fuel when an Ultra Low Sulfur diesel is being used.

Install and regularly service a good, visual-type fuel filter/water separator between the fuel tank and the engine. The Raycor 500 MA or 230 RMAM are good examples of such filters. A 10 micron filter element is recommended.

ENGINE OIL

Use a good brand of engine oil, with an API classification and SAE as stated in the SPECIFICATIONS section of this manual. Change the engine oil and oil filter after the initial 50 hours of engine break-in operation and then every 100 hours of operation thereafter.

Westerbeke Corporation does not approve or disapprove of the use of synthetic oil. If synthetic oil is used, engine break-in must be performed using conventional oil. Oil change intervals must be as listed in the MAINTENANCE SCHEDULE section of this manual and not to be extended if synthetic oil is used.

NOTE: *The information above supersedes all previous statements regarding synthetic oil.*

ENGINE COOLANT

WESTERBEKE recommends a mixture of 50% antifreeze and 50% distilled water. Distilled water is free from the chemicals that can corrode internal engine surfaces.

The antifreeze performs double duty. It allows the engine to run at proper temperatures by transferring heat away from the engine to the coolant, and lubricates and protects the cooling circuit from rust and corrosion. Look for a good quality antifreeze that contains Supplemental Cooling Additives (SCAs) that keep the antifreeze chemically balanced, crucial to long term protection.

The distilled water and antifreeze should be premixed before being poured into the cooling circuit.

NOTE: *Look for the new environmentally-friendly long lasting antifreeze that is now available.*

PURCHASING ANTIFREEZE


Select a brand of antifreeze specified for diesel engines. Antifreeze specified for diesel engines contains a special additive to protect against cavitation erosion of the engine's cylinder walls. Prestone and Zerex are two nationally known brands that offer antifreeze specifically for use in diesel engines. Select the pre-mixed variety so that the correct mixture will always be added to the cooling system when needed. Change the antifreeze mixture according to the MAINTENANCE SCHEDULE in this manual.

MAINTENANCE

Change the engine coolant every five years regardless of the number of operating hours as the chemical additives that protect and lubricate the engine have a limited life.

COOLANT RECOVERY TANK

The coolant recovery allows for the expansion and contraction of the engines coolant during engine operation without introducing air into the system. This recovery tank is provided with fresh water cooled models and with the fresh water coolant conversion kit and must be installed before operating the engine.



NOTE: *This tank, with its short run of plastic hose, is best located at or above the level of the engine's manifold, but it can be located below the level of the engine's manifold if the particular installation makes this necessary.*

GENERATOR CONTROL PANELS

DESCRIPTION OF SWITCHES

This manually controlled series of WESTERBEKE marine diesel generators is equipped with toggle switches on the engine control panel and, optionally, at remote panels.

All three switches are momentary contact type and serve the following functions:



PREHEAT: The PREHEAT toggle switch serves two purposes: preheating the engine for easy starting and defeating of bypassing the engine oil pressure switch. The defeat function turns on the fuel solenoid, instrument power and alternator excitation.

When the PREHEAT switch is depressed, the voltmeter, panel lights, gauges and meters and fuel solenoid will activate.


START: The START toggle switch closes the K1 relay that energizes the starter solenoid and activates the starter. While the PREHEAT switch is still depressed, depressing the START switch engages the start solenoid. When the engine begins to fire, the START switch should be released. The PREHEAT switch should not be released until the oil pressure reaches 5 - 10 psi.

STOPPING: The STOP toggle switch is a normally closed switch a DC path through the three automatic shutdown switches to the K2 run relay. Opening this switch terminates this DC path to the K2 run relay shutting down the engine.

To stop the engine, simply depress the STOP switch. The DC path to the K2 run relay is terminated, de-energizing the relay and the engine shuts down. The STOP switch should be held depressed until the generator shuts down completely.

NOTE: When the engine is shut down, the water temperature gauge and the oil pressure gauge will continue to register the last temperature and oil pressure readings displayed. They will return to zero once electrical power is restored.

EMERGENCY STOP: The EMERGENCY stop switch on the side of the control box, is normally closed. When depressed, it will open the DC circuit to the control panel and shut the engine down. As the switch is not toggled it can be used when performing maintenance.



DESCRIPTION OF GAUGES

Coolant Temperature

Engine coolant (water) temperature should normally indicate 175° to 195° F (80° to 90° C).

Engine Oil Pressure

Oil pressure (psi) may fluctuate depending on the generator load but should range between between 30 to 60 psi.

DC Voltmeter

Indicates the amount the battery is being charged should show 13.5V to 14.4V.

Hourmeter

Registers elapsed time and is used as a guide for when to perform scheduled maintenance.

REMOTE PANEL

For remote operation of the generator system, the same three switches are used. The PREHEAT and START switches are connected in parallel with the gauge panel's switches and serve the same functions as in the gauge panel. The STOP switch is in series with the gauge panel's STOP switch and serves the same function. There is a REMOTE START/STOP WIRING DIAGRAM in this manual.



NOTE: For additional information on Control Panels. Refer to: STARTING/STOPPING PROCEDURE, DC WIRING DIAGRAMS and TROUBLESHOOTING GAUGES.


PREPARATIONS FOR INITIAL START-UP

PRESTART INSPECTION

This section of the manual provides the operator with preparation, initial starting, break-in, starting (warm or cold) and stopping procedures. Follow the procedures as presented for the conditions indicated and your WESTERBEKE generator set will give reliable performance and long service life.

Before starting your generator set for the first time or after a prolonged layoff, check the following items:

- Check the engine oil level. Add oil to maintain the level at the high mark on the dipstick.
- Check the fuel supply and examine the fuel filter/separator bowls for contaminants.
- Check the DC electrical system. Inspect wire connections and battery cable connections. Make certain the (+) battery cable is connected to the starter solenoid and the negative (-) cable is connected to the engine ground stud (this location is tagged).
- Check the coolant level in both the plastic recovery tank and at the manifold.
- Visually examine the unit. Look for loose or missing parts, disconnected wires, unattached hoses, and check threaded connections.
- Check load leads for correct connection as specified in the wiring diagrams.
- Examine air inlet and outlet for air flow obstructions.
- Be sure no other generator or utility power is connected to load lines.
- Be sure that in power systems with a neutral line that the neutral is properly grounded (or ungrounded) as the system requires, and that the generator neutral is properly connected to the load neutral. In single phase and some 3-phase systems an incomplete or open neutral can supply the wrong line-to-neutral voltage on unbalanced loads.
- Make sure the mounting installation is secure.
- Make sure that the generator is properly grounded.



CAUTION: When starting the generator, it is recommended that all AC loads, especially large motors, be switched OFF until the engine has come up to speed and, in cold climates, starts to warm up. This precaution will prevent damage caused by unanticipated operation of the AC machinery and will prevent a cold engine from stalling.


GENERATOR VOLTAGE

The speed of the generator engine is adjusted at the factory, however, it is advisable to verify.

60 hertz The engine no-load speed is set at 61.5 - 62 Hz. At rated amperage hertz output may decrease to 58.5 - 59.0 Hz.

50 hertz The engine no-load speed is set at 51.5 Hz. At rated amperage hertz output may decrease to 48.5 - 49.0 Hz.

The speed of the generator engine is adjusted at the factory, however it is advisable to verify. The voltages are easily adjusted to optimum values no-load and full-load (refer to *VOLTAGE ADJUSTMENT* in this manual). If possible, apply actual service load or test load of the same power factor as the load to be used in service. If the voltage cannot be adjusted to suitable values and a fault seems evident, contact your authorized WESTERBEKE service dealer.



SAFETY SHUTDOWN SWITCHES AND SENSORS


SAFETY SHUTDOWN SWITCHES

The engine is protected by three automatic shutdown switches. Should shutdown occur, *do not attempt to restart without finding and correcting the cause. Refer to the heading "Engine Stops" in the TROUBLESHOOTING section of this manual.*

The following is a description of these automatic shutdown switches:


High Exhaust Temperature Switch

An exhaust temperature switch is located on the water injected exhaust elbow. Its contacts are normally closed. If the contacts open due to a high coolant temperature, the DC run circuit is interrupted and the unit shuts down. The switch's contact open at 260° - 270°F (127° - 127°C). The switch's contacts close when the temperature lowers to approximately 225°F (107°C).




Engine Coolant Temperature Switch

A high engine coolant temperature switch located on the thermostat housing. Its contacts are normally closed. If the contacts open due to a high coolant temperature, the DC run circuit is interrupted and the unit shuts down. The switch's contact open at approximately 210°F (99°C). The switch's contacts close when the coolant temperature lowers to 195°F (107°C).




Low Oil Pressure Switch

A low oil pressure switch is located off the engine's oil gallery adjacent to the oil filter. Its contacts are normally open when the engine is in a static state, this switch's sensor monitors the engine's oil pressure. Oil pressure closes the contacts. Should the engine's oil pressure fall to 5-10 psi, the contacts open interrupting the DC run circuit shutting the unit down.



Engine DC Circuit Breaker

The engine's DC circuit is protected by an engine mounted 230 amp DC breaker. Should amperage in excess of 20 amps by draw through the breaker caused by an issue with the engine's DC circuit, it will open and shut the unit down. Investigate the issue and then manually reset the breaker. This is done by pushing the red button in.



The wiring connections to these components are shown in the WIRING DIAGRAMS in this manual.


STARTING/STOPPING PROCEDURE

THE STARTING SYSTEM


Westerbeke diesel generators use electric starters assisted by glow plugs for both normal and cold weather starting. The illustration below shows a cross-sectional view of one cylinder. The glow plug is located in the combustion chamber so that its tip is in the injector nozzle's spray path. When the glow plug is energized by the PREHEAT button, the plug glows red at the tip and assists in igniting the fuel. The result is a rapid start with less wear on the starter.

This system is common to WESTERBEKE diesels. The start circuitry is designed so that the PREHEAT button must be depressed for the time specified in the preheat chart. Then, while keeping the PREHEAT button engaged, the START button is depressed to crank the engine.

NOTE: The START switch will not energize unless the PREHEAT switch is depressed. Depressing the PREHEAT switch activates the glow plugs in the cylinder head so use the PREHEAT intermittently to avoid overheating the glow plugs.



START: While still depressing the PREHEAT switch, depress the START switch. This will engage the starter solenoid. Upon engine starting, release the START switch. Do not release the PREHEAT switch until the oil pressure reaches 5 - 10 psi. Then as long as the high water temperature and low oil pressure protective circuits do not activate, the engine will remain energized and continue to run.



NOTE: When starting:
A voltage drop will occur
when the preheat switch
is depressed.

Once the engine starts, check the engine's instruments for proper oil pressure and battery charging voltage. Apply a light load to the generator and allow the engine's operating temperature to come up to 140-150° (60-66° C) before applying heavy loads.

NOTE: Some unstable running may occur in a cold engine. Depressing the PREHEAT switch for 10-15 second intervals will help stabilize the engine rpm until the operating temperature reaches 140 - 150° F and a load is applied to the engine.

Failure to Start

Should the engine not start when the START switch is depressed for 10 to 20 seconds, release both switches and wait 30 seconds; repeat the procedure above and preheat longer. *Never run the starter for more than 30 seconds.*

CAUTION: Prolonged cranking intervals without the engine starting can result in the engine exhaust system filling with raw water. This may happen because the pump is pumping raw water through the raw water cooling system during cranking. This raw water can enter the engine's cylinders by way of the exhaust manifold once the exhaust system fills. Prevent this from happening by closing the raw water supply through-hull shut-off, draining the exhaust muffler, and correcting the cause of the excessive engine cranking. Engine damage resulting from raw water entry is not a warrantable issue; the owner/operator should keep this in mind.

Remote Starting Procedure

The remote start panel is the same as the engine-mounted start panel except that it has a green LED light and no gauges. When starting at a remote location, the green LED lights when the generator is running at approximately 600 rpm. This indicates when the START switch can be released since the starting of the generator may not be audible.

- A. When the PREHEAT switch is depressed at the remote start/stop panel the LED light will illuminate. When the START switch is depressed and the starter cranks the engine this LED light will dim. When the engine starts the LED light will brighten signaling to release the START switch. Continue to hold the PREHEAT depressed for a few seconds to allow oil pressure to build up which closes the oil pressure safety switch that is in the series path for 12V B+ to the fuel run solenoid. The green LED will remain brightly illuminated while the engine is running.
- B. After the generator is started and the START switch is released, the generator's starter will not crank unless the PREHEAT switch is operated first because this switch supplies voltage to the START switch.

STOPPING PROCEDURE

1. Remove the AC electrical load from the generator and allow the generator to run for three to five minutes to stabilize its operating temperatures.
2. Depress the STOP switch and hold it until the generator is completely stopped.
3. Now release the STOP switch.

Remote Stopping Procedure

To stop the generator, depress the STOP switch which opens the normally closed B+ path for voltage to the engine's run circuit. The STOP switch must be held open until the generator comes to a complete stop and the green LED light goes out.

GENERATOR BREAK-IN PROCEDURE

DESCRIPTION

Although your engine has experienced a minimum of one hour of test operations at the factory to make sure accurate assembly procedures were followed and that the engine operated properly, a break-in time is required. The service life of your engine is dependent upon how the engine is operated and serviced during its initial hours of use.

Breaking-in a new engine basically involves seating the piston rings to the cylinder walls. Excessive oil consumption and smoky operation indicate that the cylinder walls are scored, which is caused by overloading the generator during the break-in period.

Your new engine requires approximately 50 hours of initial conditioning operation to break in each moving part in order to maximize the performance and service life of the engine. Perform this conditioning carefully, keeping in mind the following:

Start the engine according to the *STARTING PROCEDURE* section. Run the engine while checking that all systems (raw water pump, oil pressure, battery charging) are functioning.

AFTER START-UP

Once the generator has been started, check for proper operation and then encourage a fast warm-up. Run the generator between 20% and 60% of full-load for the first 10 hours.

CAUTION: Do not attempt to break-in your generator by running without a load.

After the first 10 hours of the generator's operation, the load can be increased to the full-load rated output, then periodically vary the load.

Avoid overload at all times. An overload is signaled by smoky exhaust with reduced output voltage and frequency. Monitor the current being drawn from the generator and keep it within the generator's rating. Since the generator operates at 1800 rpm to produce 60 hertz (or at 1500 rpm to produce 50 Hertz), control of the generator's break-in is governed by the current drawn from the generator.

CHECK THE FOLLOWING

- Monitor the control panel gauges.
- Check for leaks of fuel and engine oil.
- Check for abnormal noise such as knocking, friction, vibration and blow-back sounds.
- Confirm exhaust smoke:
 - When the engine is cold – White Smoke.
 - When the engine is warm – almost Smokeless.
 - When the engine is overloaded – some Black Smoke.

To protect against unintentional overloading of the generator, the generator's output leads should be routed through a circuit breaker that is rated at the rated output of the generator.

NOTE: Be aware of motor starting loads and the high current draw required for starting motors. This starting amperage draw can be 3 to 5 times normal running amperage. See *GENERATOR INFORMATION* in this manual.

GENERATOR ADJUSTMENTS

Once the generator has been placed in operation, there may be adjustments required for engine speed (hertz) during the engine's break-in period (first 50 hours) or after this period. A no-load voltage adjustment may also be required in conjunction with the engine's speed adjustment. See *GENERATOR INFORMATION* in this manual.

MAINTENANCE SCHEDULE

WARNING: Never attempt to perform any service while the engine is running. Wear the proper safety equipment such as goggles and gloves, and use the correct tools for each job. When servicing/replacing DC components, turn off the DC circuit breaker on the control panel or turn off the battery switch.

SCHEDULED MAINTENANCE

Maintenance procedures are all detailed in this manual.

EXPLANATION OF SCHEDULED MAINTENANCE

DAILY CHECK BEFORE START-UP

Coolant Level	Check at recovery tank, if empty, check at manifold. Add coolant if needed.
Engine Oil Level	Oil level should indicate between MAX and LOW on dipstick. Do not overfill!
Fuel/Water Separator (owner installed)	Check for water and dirt in fuel. Drain filter if necessary. Replace filter every 250 operating hours or once a year.
Fuel Supply	Use properly filtered #2 diesel with a Cetane rating of #45 or higher. Check that there is adequate fuel for the vessel's needs.
Visual Inspection of Engine NOTE: Please keep engine surface clean. Dirt and oil will inhibit the engine's ability to remain cool.	Check for fuel, oil and water and exhaust leaks. Check that the water injected exhaust elbow securing v-clamp is tight. No exhaust leaks around the elbow. Inspect wiring and electrical connections. Look for loose bolts/hardware and correct as needed.

INITIAL 50 HOURS OF OPERATION

Engine Oil and Filter	Initial engine oil and filter change at 50 hours.
*Exhaust System	Check security of water injected exhaust elbow to exhaust manifold. Ensure there are no leaks.
*Valve Adjustment (cold)	Check adjustment of valves.
*Cylinder Head (cold)	Torque cylinder head hold-down bolts.
Fuel Filter(s)	Initial change.
Generator	Check that AC connections are secure with no chafing.
Engine Speed	Adjust as needed. Lubricate linkage.
Water Pump	Adjust belt tension (3/8 - 1/2 deflection).

EVERY 50 OPERATING HOURS OR MONTHLY

Drive Belt	Inspect for proper tension (3/8" to 1/2" deflection) and adjust if needed. Check belt for slipping, cracking and wear. Adjust tension or replace as needed. Replace cover.
Starting Batteries	Check electrolyte levels. Make sure cables and connections are in good order. Clean off corrosion if needed. Apply petroleum jelly to terminals for corrosion protection.
Electric Fuel Pump	Inspect for leaks, ensure fuel and electrical connections are clean and tight.
Zinc Anode	Inspect and clean zinc anode. Replace if necessary. Note the condition, then determine your own inspection schedule.

EVERY 100 OPERATING HOURS OR YEARLY

Engine Oil and Filter	Change engine oil and filter at 100 operating hours or yearly.
Air Intake Silencer	Keep air intake clear of obstructions.
Speed Linkage	Lubricate linkage between throttle and solenoid.
Impeller	Inspect impeller for condition. Replace as needed.
Syphon Break	Check for proper operation (when installed).

*WESTERBEKE recommends this service be performed by an knowledgeable mechanic.

MAINTENANCE SCHEDULE

NOTE: Use the engine hourmeter gauge to log your engine hours or record your engine hours running time.

SCHEDULED MAINTENANCE

EXPLANATION OF SCHEDULED MAINTENANCE

EVERY 250 OPERATING HOURS OR YEARLY	
Exhaust Elbow/Exhaust System	Check the structural integrity of the water injected exhaust elbow casting. Check of the exhaust system attached to the elbow. All hose connections should be chaffing. No exhaust leaks. Hoses and muffler are in good serviceable condition. NOTE: An exhaust leak will cause exposure to diesel exhaust!
Fuel Filter and O-Rings	Remove and replace fuel filter and all sealing O-rings.
*Generator	Check that AC connections are clean and secure. Ensure wires have no chafing. See <i>GENERATOR INFORMATION</i> .
Hoses	Engine hoses should be firm and tight. Replace if hoses become spongy, brittle or delaminated. Check and tighten all hose clamps as needed.
Fuel Water Separator Filter	Inspect bowl for dirt or water in fuel. Drain and replace filter.
DC Alternator	Inspect wiring, connections should be tight. Alternator should be clean and free of corrosion. Check mounting bracket and alternator bolt. All should be tight.
Impeller	Remove impeller from raw water pump. Inspect impellers condition. Replace as needed.
EVERY 500 OPERATING HOURS OR FIVE YEARS	
Raw Water Pump	Remove and disassemble the pump and inspect all parts: drive gear, pump shaft, wear plate and cover for wear and corrosion. Replace the impeller and gasket. Lubricate the impeller at re-assembly.
Coolant System	Drain, flush and re-fill the cooling system with appropriate antifreeze mix. Inspect the condition of the sealing gaskets of the pressure cap. Clean out coolant recovery tank and connecting hose.
*Valve Clearances/Cylinder Head(cold)	Torque head bolts then adjust valves.
*Starter Motor	Check solenoid and motor for corrosion. Remove and lubricate. Clean and lubricate the starter motor pinion drive.
Fuel Injectors	Check and adjust injection opening pressure and spray conditions.
EVERY 1000 OPERATING HOURS OR OR EVERY FIVE YEARS	
Heat Exchanger	Remove the heat exchanger for professional cleaning and pressure testing.
Glow Plugs	Check circuit. Remove, clean, check resistance.

*WESTERBEKE recommends this service be performed by an knowledgeable mechanic.

COOLING SYSTEM


DESCRIPTION

Westerbeke marine diesel engines are designed and equipped for fresh water cooling. Heat produced in the engine by combustion and friction is transferred to fresh water coolant which circulates throughout the engine. This circulating fresh water coolant cools the engine block, its internal moving parts, and the engine oil. The heat is transferred externally from the fresh water coolant to raw water by means of a heat exchanger, similar in function to an automotive radiator. Raw water flows through the tubes of the heat exchanger while fresh water coolant flows around the tubes; engine heat transferred to the fresh water coolant is conducted through the tube walls to the raw water which is then pumped into the exhaust system where finally it is discharged overboard. In other words, the engine is cooled by fresh water coolant, this coolant is cooled by raw water, and the raw water carries the transferred heat overboard through the exhaust system. The fresh water coolant and raw water circuits are independent of each other. Using only fresh water coolant within the engine allows the cooling water passages to stay clean and free from harmful deposits.

FRESH WATER COOLING CIRCUIT

NOTE: Refer to the *ENGINE COOLANT* section for the recommended antifreeze and water mixture to be used as the fresh water coolant.

Fresh water coolant is pumped through the engine by a circulating pump, absorbing heat from the engine. The coolant then passes through the thermostat into the manifold, to the heat exchanger where it is cooled, and returned to the engine block via the suction side of the circulating pump.



When the engine is started cold, external coolant flow is prevented by the closed thermostat (although some coolant flow is bypassed around the thermostat to prevent the exhaust manifold from overheating). As the engine warms up, the thermostat gradually opens, allowing full flow of the engine's coolant to flow unrestricted to the external portion of the cooling system.

Coolant Recovery Tank

A coolant recovery tank allows for engine coolant expansion and contraction during engine operation, without any significant loss of coolant and without introducing air into the cooling system. This tank should be located at or above the engine manifold level and should be easily accessible.

CHANGING COOLANT


The engine's coolant must be changed according to the *MAINTENANCE SCHEDULE*. If the coolant is allowed to become contaminated, it can lead to overheating problems.

CAUTION: Proper cooling system maintenance is critical; a substantial number of engine failures can be traced back to cooling system corrosion.

Drain the engine coolant by loosening the drain plug on the engine block and opening the manifold pressure cap. Flush the system with fresh water, then start the refill process.

NOTE: The drain petcock on the heat exchanger should also be used to help drain engine coolant.


WARNING: Beware of the hot engine coolant. Wear protective gloves.



COOLING SYSTEM

CHANGING THE RAW WATER PUMP IMPELLER

Close the raw water intake valve. Remove the pump cover and gasket or O-ring with the aid of two screwdrivers or pliers. Carefully pry/pull the impeller out of the pump. Lightly coat the inside of the pump housing with *glycerine*. Install the new impeller, bending the blades in the direction of the curve of the cam plate. Re-assemble the gasket and cover. Open the raw water intake valve.



CAUTION: If any of the vanes have broken off the impeller, they must be found to prevent blockage in the cooling circuit. They often can be found in the heat exchanger.

Raw Water Intake Strainer

NOTE: Always install the strainer at or below the waterline so the strainer will always be self-priming.


A clean raw water intake strainer is a vital component of the engine's cooling system. Include a visual inspection of this strainer when making your periodic engine check. The water in the glass should be clear.

Perform the following maintenance after every 100 hours of operation:

1. Close the raw water seacock.
2. Remove and clean the strainer filter.
3. Clean the glass.
4. Replace the washer if necessary.
5. Reassemble and install the strainer.
6. Open the seacock.
7. Run the engine and check for leaks.


NOTE: Also follow the above procedure after having run hard aground.

If the engine temperature gauge ever shows a higher than normal reading, the cause may be that silt, leaves or grass may have been caught up in the strainer, slowing the flow of raw water through the cooling system.



HEAT EXCHANGER

The heat exchanger is a copper cylinder which encloses a number of small copper tubes. Raw water is pumped through the small copper tubes and the fresh water coolant from the engine is circulated around the copper tubes. The raw water removes heat from the fresh water coolant.



HEAT EXCHANGERS ARE ALSO AVAILABLE WITH CUPRO-NICKEL TUBING

COOLING SYSTEM

Refilling the Coolant


After replacing the engine block drain plug, close the heat exchanger's coolant petcock. Then pour clean, premixed coolant into the manifold and when the coolant is visible in the manifold, start the engine.

NOTE: Open the air-bleed petcock on the heat exchanger. When a steady flow of coolant appears at the petcock, close the petcock and fill the system until the manifold remains full.

Monitor the coolant in the manifold and add as needed. Fill the manifold to the filler neck and install the manifold pressure cap.

Remove the cap on the coolant recovery tank and fill with coolant mix to halfway between LOW and MAX and replace the cap. Run the engine and observe the coolant expansion flow into the recovery tank.

After checking for leaks, stop the engine and allow it to cool. Coolant should draw back into the cooling system as the engine cools down. Add coolant to the recovery tank if needed. Clean up any spilled coolant.



NOTE: Periodically check the condition of the manifold pressure cap. Ensure that the upper and lower rubber seals are in good condition and check that the vacuum valve opens and closes tightly. Carry a spare cap.




THERMOSTAT

A thermostat, located near the manifold at the front of the engine, controls the coolant temperature as the coolant continuously flows through the closed cooling circuit. When the engine is first started, the closed thermostat prevents coolant from flowing (some coolant is by-passed through a hole in the thermostat to prevent the exhaust manifold from overheating). As the engine warms up, the thermostat gradually opens. The thermostat is accessible and can be checked, cleaned, or replaced easily. Carry a spare thermostat and gasket.

Replacing the Thermostat

Remove the cap screws and disassemble the thermostat housing as shown. When installing the new thermostat and gasket, apply a thin coat of sealant on both sides of the gasket before pressing it into place. Do not over-tighten the cap screws.

Run the engine and check for normal temperatures and that there are no leaks at the thermostat housing.



RAW WATER COOLING CIRCUIT

The raw water flow is created by a positive displacement impeller pump. This pump draws water directly from the raw water source (ocean, lake, or river) through a hose to the water strainer. The raw water passes from the strainer through the raw water pump to the heat exchanger (through the heat exchanger tubes) where it cools the engine circulating fresh water coolant. The raw water is then discharged into the water-injected exhaust elbow, mixing with and cooling the exhaust gasses. This mixture of exhaust gas and raw water is discharged overboard by the engine's exhaust gas discharge pressure.

Raw Water Pump


The raw water pump is a self-priming, rotary pump with a non-ferrous housing and a neoprene impeller. The impeller has flexible vanes which wipe against a curved cam plate within the impeller housing, producing the pumping action. On no account should this pump be run dry as water acts as a lubricant for the impeller. There should always be a spare impeller and impeller cover gasket (an impeller kit) aboard. Raw water pump impeller failures occur when lubricant (raw water) is not present during engine operation. Such failures are not warrantable, and operators are cautioned to make sure raw water flow is present at start-up.

NOTE: Should a failure occur with the pump's internal parts (seals and bearings), it may be more cost efficient to purchase a new pump and rebuild the original pump as a spare.

COOLING SYSTEM

Zinc Anode

A zinc anode, or *pencil*, is located in the raw water cooling circuit within the heat exchanger. The purpose of having the zinc anode is to sacrifice itself to electrolysis action taking place in the raw water cooling circuit, thereby reducing the effects of electrolysis on other components of the system. The condition of the zinc should be checked monthly to determine its service life. Once that is established, the zinc replacement period can be noted in your maintenance log. Spare zinc anodes should be carried on board.



NOTE: Electrolysis action is the result of each particular installation and vessel location; not that of the engine.

If the zinc anodes need replacement, hold the hex boss into which the zinc anode is threaded with a wrench while loosening the anode with another wrench. This prevents the hex boss from possibly tearing off the exchanger shell. After removing the zinc, note the condition of it. If the zinc is in poor condition, there are probably a lot of zinc flakes within the exchanger. Remove the end of the heat exchanger and clean the inside of all zinc debris. Always have a spare heat exchanger end gasket in case the present one becomes damaged when removing the end cover. Replace the gasket (refer to your engine model's heat exchanger end gasket part number), O-ring and cover, and install a new zinc anode.

NOTE: The threads of the zinc anodes are pipe threads and do not require sealant. Sealant should not be used as it may insulate the zinc from the metal of the heat exchanger housing preventing electrolysis action on the zinc.

Heat Exchanger Service

After approximately 1000 hours of operation, remove, clean and pressure test the engine's heat exchanger. (A local automotive radiator shop should be able to clean and test the heat exchanger.)


NOTE: Operating in silty and/or tropical waters may require that a heat exchanger cleaning be performed more often than every 1000 hours.

AIR INTAKE SILENCER

AIR INTAKE SILENCER

The function of the air intake silencer is to reduce the pulsating air intake noise produced by a diesel engine while operating.

The air intake silencer has no filter element inside. The only maintenance it requires is that the inlet opening be kept clear of any obstructions to air flow into the silencer.



FUEL SYSTEM


DIESEL FUEL

Use a diesel fuel that meets the requirements of No.2-D SAE J 313 and has a cetane rating of 45 or higher according to ASTM D975.


DESCRIPTION

Fuel is drawn into the engine's fuel system by the electric fuel pump mounted on the generator's drive engine. Fuel is drawn from the fuel tank through the primary fuel filter/water separator through the fuel pump, then under pressure (6-8 psi) and delivered to the secondary fuel filter mounted on the engine. Fuel passes through this filter to the fuel injection pump where the injection pump delivers it to the injectors. The fuel serves three purposes in the system. It is used for combustion, lubrication and carries heat away from the injection equipment through the return back to the fuel tank where it is dissipated in the cool fuel in the tank.

FUEL SYSTEM DIAGRAM (TYPICAL)



PRIMARY FUEL FILTER WATER SEPARATOR



FUEL WATER SEPARATOR

A primary fuel filter of the water separating type must be installed between the fuel tank and the engine to remove water and other contaminants from the fuel before they can be carried to the fuel system on the engine.


A typical fuel filter/water separator is illustrated below. This is the *Raycor Model 500 MA*. Keep in mind that if a water separator type filter is not installed between the fuel supply tank and engine-mounted fuel system, any water in the fuel will affect the fuel pump, engine filter, and injection equipment. The owner/operator is responsible for making certain the fuel reaching the engine's injection equipment is free of impurities. This process is accomplished by installing and maintaining a proper filtration/separation system.

SECONDARY ON-ENGINE FUEL FILTER

Change the filter element after the initial 50 hours of operation then follow the MAINTENANCE SCHEDULE in this manual.

Changing The Fuel Filter Element

1. Shut the fuel supply off.
2. Unscrew the retaining ring that holds the filter bowl to the housing and allow the bowl to come away from the housing. Have some absorbent towels under the bowl to catch any fuel.
3. Remove the filter element. Replace the "O" ring that the element fit on to. Clean the bowl.
4. Replace the large sealing "O" ring. Install a new element. Reassemble the bowl to the housing. Thread the retaining ring on carefully so as not to cross thread. When the retaining ring contacts the "O" ring, tighten 1/4-1/2 turn by hand. Turn on the fuel supply and bleed the engine via the preheat circuit. Then run the engine and inspect for any leaks.




FUEL SYSTEM

FUEL LIFT PUMPS

Two types of fuel lift pumps are shown, both operate on the same electromagnetic principle. Earlier model engines use a lift pump with a replaceable element. This element should be changed at regular maintenance intervals (at 250 hours).


Later model engines use a smaller lift pump that does not require maintenance. Electrical connections should be kept clean and tight with either pump.

When energized thru the preheat circuit, the fuel lift pump will purge air from the fuel system and provide a continuous flow of fuel as the engine is running.




FUEL LIFT PUMPS

ENGINE LUBRICATING OIL



1. **Draining the Oil Sump.** Discharge the used oil through the sump drain hose (attached to the front of the engine) while the engine is warm. Drain the used oil completely, replace the hose in its bracket, and replace the end cap securely.

NOTE: Thread size for the lube oil drain hose capped end is 1/4 NPT.



2. **Replacing the Oil Filter.** When removing the used oil filter, you may find it helpful and cleaner to punch a hole in the upper and lower portion of the old filter to drain the oil from it into a container before removing it. This helps to lessen spillage. A small automotive filter wrench should be helpful in removing the old oil filter.

NOTE: Do not punch this hole without first loosening the filter to make certain it can be removed.

Place some paper towels and a plastic bag around the filter when unscrewing it to catch any oil left in the filter. (Oil or any other fluid on the engine reduces the engine's cooling ability. Keep your engine clean.) Inspect the old oil filter as it is removed to make sure that the rubber sealing gasket comes off with the old oil filter. If this rubber sealing gasket remains sealed against the filter bracket, gently remove it.

When installing the new oil filter element, wipe the filter gasket's sealing surface on the bracket free of oil and apply a thin coat of clean engine oil to the rubber gasket on the new oil filter. Screw the filter onto the threaded oil filter nipple on the oil filter bracket, and then tighten the filter firmly by hand.

NOTE: Generic filters are not recommended, as the material standards or diameters of important items on generic parts might be entirely different from genuine parts. Immediately after an oil filter change and oil fill, run the engine to make sure the oil pressure is normal and that there are no oil leaks around the new oil filter.

3. **Filling the Oil Sump.** Add new oil through the oil filler cap on the top of the engine or through the side oil fill. After refilling, run the engine for a few moments while checking the oil pressure. Make sure there is no leakage around the new oil filter or from the oil drain system, and stop the engine. Then check the quantity of oil with the lube oil dipstick. Fill to, but not over the high mark on the dipstick, should the engine require additional oil.

OIL PRESSURE


The lubricating system is a pressure feeding system using an oil pump. The engine oil is drawn from the oil sump by the oil pump, which drives the oil, under pressure, through the oil filter, oil cooler and various lubricating points in the engine. The oil then returns to the oil sump to repeat the continuous cycle. When the oil pressure exceeds the specified pressure, the oil pushes open the relief valve in the oil pump and returns to the oil sump, keeping the oil pressure within its specified range.

The engine's oil pressure, during operation, is indicated by the oil pressure gauge on the instrument panel. During normal operation, the oil pressure will range between 40 and 60 psi (2.8 and 4.2 kg/cm²).

NOTE: A newly started, cold engine can have an oil pressure reading up to 60 psi (4.2 kg/cm²). A warmed engine can have an oil pressure reading as low as 35 psi (2.5 kg/cm²). These readings will vary depending upon the temperature of the engine and the rpms.

LOW OIL PRESSURE

The specified safe minimum oil pressure is 4.3 + 1.4 psi (0.3 + 0.1 kg/cm²). A gradual loss of oil pressure usually indicates a worn bearings. For additional information on low oil pressure readings, see the *ENGINE TROUBLESHOOTING* chart.




NOTE: To test the oil pressure, install a mechanical pressure gauge as shown. Warm up the engine and read the oil pressure. Oil Pressure should be 35.0 lb/in² (3.8 Kg/cm²) or more at 1800 rpm.

DC ELECTRICAL SYSTEM

ALTERNATOR

The charging system consists of a DC belt driven alternator with a voltage regulator, an engine DC wiring harness, a mounted DC circuit breaker and a battery with connecting cables. Because of the use of integrated circuits (IC's), the electronic voltage regulator is very compact and is mounted internally or on the back of the alternator.



ALTERNATOR TROUBLESHOOTING

⚠ WARNING: A failed alternator can become very hot. Do not touch until the alternator has cooled down.

Use this troubleshooting section to determine if a problem exists with the charging circuit or with the alternator. If it is determined that the alternator or voltage regulator is faulty, have a qualified technician check it.


The alternator charging circuit charges the starting battery and the service battery. An isolator with a diode, a solenoid or a battery selector switch is usually mounted in the circuit to isolate the batteries so the starting battery is not discharged along with the service battery. If the alternator is charging the starting battery but not the service battery, the problem is in the service battery's charging circuit and not with the alternator.

Testing the Alternator

⚠ CAUTION: Before starting the engine make certain that everyone is clear of moving parts! Keep away from sheaves and belts during test procedures.

⚠ WARNING: When testing with a multimeter: DC and AC circuits are often mixed together in marine applications. Always disconnect a shore power cord, isolate DC and AC converters, and shut down the engine before performing DC testing. No AC tests should be made without a proper knowledge of AC circuits.

1. Start the engine.
2. After the engine has run for a few minutes, measure the starting battery voltage at the battery terminals using a multimeter set on DC volts.
 - a. If the voltage is increasing toward 14 volts, the alternator is working; omit Steps 3 through 8 and go directly to "Checking the Service Battery" on the next page.
 - b. If the voltage remains around 12 volts, a problem exists with either the alternator or the charging circuit; continue with Steps 3 through 8.




TESTING THE STARTING BATTERY/ALTERNATOR (ENGINE RUNNING)

3. Turn off the engine. Inspect all wiring and connections. Ensure that the battery terminals and the engine ground connections are tight and clean.

⚠ CAUTION: To avoid damage to the battery charging circuit, never shut off the engine battery switch when the engine is running!


4. If a battery selector switch is in the charging circuit, ensure that it is on the correct battery.
5. Turn off the battery switch.
6. Check the battery voltage. If the battery is in good condition, the reading should be 12 to 13 volts.



TESTING THE STARTING BATTERY - ENGINE OFF

DC ELECTRICAL SYSTEM

7. Now check the voltage between the alternator output terminal (B+) and ground. If the circuit is good, the voltage at the alternator will be the same as the battery, or if an isolator is in the circuit the alternator voltage will be zero. If neither of the above is true, a problem exists in the circuit between the alternator and the battery. Check all the connections — look for an opening in the charging circuit.




8. Start the engine again. Check the voltage between the alternator output and ground. The voltage reading for a properly operating alternator should be between 13.5 and 14.5 volts. If your alternator is over- or under-charging, have it repaired at a reliable service facility.

NOTE: Before removing the alternator for repair, use a voltmeter to ensure that 12 volts DC excitation is present at the EXC terminal if the previous test showed only battery voltage at the B output terminal.

If 12 volts is not present at the EXC terminal, trace the wiring and look for breaks and poor connections.

Checking the Service Battery

Check the voltage of the service battery. This battery should have a voltage between 13 and 14 volts when the engine is running. If not, there is a problem in the service battery charging circuit. Troubleshoot the service battery charging circuit by checking the wiring and connections, the solenoid, isolator, battery switch, and the battery itself.



CAUTION: To avoid damaging the alternator diodes, do not use a high voltage tester (i.e. a megger) when performing tests on the alternator charging circuit.

12 VOLT DC CONTROL CIRCUIT

The engine has a 12 volt DC electrical control circuit that is shown on the wiring diagrams that follow. Refer to these diagrams when troubleshooting or when servicing the DC electrical system.

CAUTION: To avoid damage to the battery charging circuit, never shut off the engine battery switch while the engine is running. Shut off the engine battery switch, however, to avoid electrical shorts when working on the engine's electrical circuit.

BATTERY

The minimum recommended capacity of the battery used in the engine's 12 volt DC control circuit is 600 – 900 Cold Cranking Amps (CCA).

Battery Care

Review the manufacturer's recommendations and then establish a systematic maintenance schedule for your engine's starting batteries and house batteries.

- Monitor your voltmeter for proper charging during engine operation.
- Check the electrolyte level and specific gravity with a hydrometer.
- Use only distilled water to bring electrolytes to a proper level.
- Make certain that battery cable connections are clean and tight to the battery posts (and to your engine).
- Keep your batteries clean and free of corrosion.

WARNING: Sulfuric acid in lead batteries can cause severe burns on skin and damage clothing. Wear protective gear.

STARTER MOTOR

DESCRIPTION

The starter can be roughly divided into the following sections:

- A motor section which generates a drive power.
- An overrunning clutch section which transmits an armature torque, preventing motor overrun after starting.
- A switch section (solenoid) which is operated when actuating the overrunning clutch through a lever and which supplies load current to the motor.

The starter is a new type, small, light-weight and is called a high-speed internal-reduction starter. The pinion shaft is separate from the motor shaft; the pinion slides only on the pinion shaft. A reduction gear is installed between the motor shaft and a pinion shaft. The pinion sliding part is not exposed outside the starter so that the pinion may slide smoothly without becoming fouled with dust and grease. The motor shaft is supported at both ends on ball bearings. The lever mechanism, switch and overrunning clutch inner circuit are identical to conventional ones.

ADJUSTMENT AND REPAIR


If any abnormality is found by the following tests, the starter should be disassembled and repaired.

Pinion Gap Inspection

1. Connect a battery (12V) between the starter terminal S and the starter body, and the pinion drive should rotate out and stop.

CAUTION: Never apply battery voltage for over 10 seconds continuously.


2. Lightly push the pinion back and measure the return stroke (called pinion gap).
3. If the pinion gap is not within the standard range, (0.5 to 2.0 mm), adjust it by increasing or decreasing the number of shims on the solenoid. The gap is decreased as the number of shims increases.



PINION GAP

No-Load Test

1. Connect the ammeter, voltmeter, and battery to the starter as illustrated.
2. When the switch is closed, the pinion must protrude and the starter must run smoothly (at 3000 rpm or more). If the current or starter speed is out of specification, disassemble the starter and repair it.




CAUTION: Use thick wires as much as possible and tighten every terminal securely. This is a solenoid shift-type starter which makes a rotating sound louder than that of a direct-drive type starter. When detecting starter rotation at the pinion tip, be careful not to come in contact with the pinion gear when it protrudes.

SOLENOID

Perform the following tests. If any test result is not satisfactory, replace the solenoid assembly.

1. Inspect the solenoid for continuity between terminals (+) and (-) and between terminals S and the body and M and the body. There should be no continuity found between terminals S and M. Continuity will be found between terminals S and the body and terminal M and the body.




NOTE: Disconnect the wire from terminal M.


2. Connect a battery to the solenoid's terminal S for (+) and M for (-). Have a switch in the + lead and close it. The pinion drive should extend fully out.

CAUTION: Do not apply battery current for more than 10 seconds when testing the solenoid.

STARTER MOTOR




3. **Holding test.** With a battery connected to the solenoid terminal S (+) and to the starter body, manually pull out the pinion fully. The pinion must remain at that position even when released from holding with your hand.



4. **Return test.** With a battery connected to the solenoid terminal M (-) and to the starter body, manually pull out the pinion fully. The pinion must return to its original position when released from holding by hand.

RETURN TEST




SERVICE

WESTERBEKE uses a standard starter motor which can be serviced or rebuilt at any starter motor automotive service center. Starter motors used on marine gasoline units must be ignition protected. Use only a genuine Westerbeke replacement starter.

STARTER DISASSEMBLY

1. Disconnect the wire from the solenoid terminal M (-).
2. Loosen the two screws fastening the solenoid. Remove the solenoid assembly.
3. Remove the two long through bolts and two screws fastening the brush holder. Remove the rear bracket.
4. With the brushes pulled away from the armature, remove the yoke and brush holder assembly. Then pull the armature out.
5. Remove the cover, pry the snap ring out, and remove the washer.
6. Unscrew the bolts and remove the center bracket. At the same time, the washers for the pinion shaft end play adjustment will come off.
7. Pull out the reduction gear lever and lever spring from the front bracket.
8. On the pinion side, pry the snap ring out, and pull out the pinion and pinion shaft.
9. At each end of the armature, remove the ball bearing with a bearing puller. It is impossible to replace the ball bearing press-fitted in the front bracket. If that bearing has worn off, replace the front bracket assembly.




NOTE: Inspect, clean and replace if necessary brush, commutator, solenoid, armature, etc. See the following pages.

ENGINE ADJUSTMENTS

NOTE: WESTERBEKE recommends that the following engine adjustments be performed by a competent engine mechanic. The information below is provided to assist the mechanic.

GLOW PLUGS TYPICAL



DESCRIPTION

The glow plugs are wired through the preheat solenoid. When PREHEAT is pressed at the control panel this solenoid should “click” on and the glow plug should begin to get hot.

INSPECTION

To inspect the plug, remove the electrical terminal connections, then unscrew or unclamp each plug from the cylinder head. Thoroughly clean each plug’s tip and threads with a soft brush and cleaning solution to remove all the carbon and oil deposits. While cleaning, examine the tip for wear and burn erosion; if it has eroded too much, replace the plug.

TESTING

An accurate way to test glow plugs is with an ohmmeter. Touch one prod to the glow plug’s wire connection, and the other to the body of the glow plug, as shown. A good glow plug will have a 1.0- to 1.5-ohm resistance. This method can be used with the plug in or out of the engine. You can also use an ammeter to test the power drain (8 to 9 amps per plug).

WARNING: These glow plugs will become very hot to the touch. Be careful not to burn your fingers when testing the plugs

Re-install the plugs in the engine and test them again. The plugs should get very hot (at the terminal end) within 20 to 25 seconds. If the plugs don’t heat up quickly, check for a short circuit. When reinstalling the glow plugs, use anti-seize compound on the threads.

Glow Plug Tightening Torque 7 - 11 lb-ft (1.0 - 1.5 kg-m)

WARNING: Do not keep a glow plug on for more than 30 seconds

FUEL INJECTORS

In case of severe vibrations and detonation noise, have the injectors checked and overhauled by an authorized fuel injection service center. Poor fuel quality, contaminants and loss of positive fuel pressure to the injection pump can result in injector faults. Since fuel injectors must be serviced in a clean room environment, it is best to carry at least one extra injector as a spare should a problem occur.

Before removing the old injector, clean the area around the base of the injector to help prevent any rust or debris from falling down into the injector hole. If the injector will not lift out easily and is held in by carbon build-up or the like, work the injector side-to-side with the aid of the socket wrench to free it, and then lift it out.

The injector seats in the cylinder head on a copper sealing washer. This washer should be removed with the injector and replaced with a new washer when the new injector is installed.

Injector to Cylinder Head Tightening Torque 40 ± 4 ft-lb (5.5 ± 0.5 kgf-m)



FUEL INJECTOR

REFER TO YOUR WESTERBEKE SERVICE MANUAL FOR TESTING AND SERVICING OF FUEL INJECTORS.

ENGINE ADJUSTMENTS

NOTE: WESTERBEKE recommends that the following engine adjustments be performed by a competent engine mechanic. The information below is provided to assist the mechanic.

GENERATOR FREQUENCY ADJUSTMENT (HERTZ)

Once the diesel generator set has been placed in operation, there may be adjustments required for engine speed (Hertz) during the engine's break-in period (first 50 Hours) or after this period. A no-load voltage adjustment may also be required in conjunction with the engine's speed adjustment. These are not warrantable adjustments as they relate to normal break-in and maintenance.

Frequency is a direct result of engine/generator speed, as indicated by the following:


When the generator is run at 1800 rpm, the AC output voltage frequency is 60 hertz.

When the generator is run at 1500 rpm, the AC output voltage frequency is 50 hertz.

1. Connect the AC output leads to the AC terminal block in accordance with AC Voltage Connections diagram specified for your generator set, which appears in the BT GENERATOR section of this manual.
2. Adjust the engine's speed to obtain the frequency corresponding to the voltage selected by extending or shortening the Throttle Adjustment Linkage. Make sure the solenoid's plunger is completely bottomed in the solenoid.

Failure of the solenoid to bottom in the solenoid will result in a failed solenoid.

To avoid failure of the solenoid, ensure that the solenoid plunger bottoms in the solenoid. Check the solenoid's operation at the initial start-up. Periodically lubricated linkage joints between the solenoid plunger and the throttle joints between the solenoid plunger and the throttle arm will eliminate binding.



NOTE: The solenoid plunger **must** move smoothly and rapidly into the solenoid when the solenoid is electrically energized, drawing the engine's throttle arm into the Set Speed/Run Position.

To arrive at the appropriate frequency, either monitor the speed of the engine/generator with a tachometer or monitor the frequency with a frequency meter. The latter method being the more precise of the two.

DRIVE BELT ADJUSTMENT


CAUTION: Drive belts must be properly tensioned. Loose drive belts will not provide proper alternator charging and will eventually damage the alternator.

Drive belts that are too tight will pull the alternator out of alignment and/or cause the alternator to wear out prematurely.

Belt tension adjustment is made by pivoting the alternator on its base mounting bolt.

1. Loosen the alternator adjusting strap bolt and the base mounting bolt.
2. Pivot the alternator on the base mounting bolt to the left or right as required.

3. Tighten the base mounting bolt and the adjusting strap bolt.
4. Operate the engine for about 5 minutes at idle, then shut down and recheck belt tension.



ENGINE ADJUSTMENTS

11.0KW BTD & 12.5KW BTD(A)

VALVE CLEARANCE ADJUSTMENT

Adjust the valve clearance when the engine is cold.
0.0098 inches (0.25 mm). Tighten the cylinder head bolts to the specified torque and sequence shown below.

1. Pull off the air breather pipe from the rocker cover, and take off the rocker cover bolts.
2. Adjust the valve clearances at TDC (Top Dead Center) for each cylinder when they are on their compression stroke.
3. Make sure that the timing mark on the gear case and timing mark on the crankshaft pulley are exactly aligned.
If not, the valve will interfere with the piston because of improper cam positioning.

NOTE: Retighten the cylinder head bolts before the valve clearance is adjusted.

11.0KW BTD & 12.5KW BTDA

BOLTS 5,6,7,8,9,10,11,12,13 & 14
17mm (11.5 - 12.5kg-m) 83.1 - 86.7 ft-lbs

BOLTS 1,2,3 & 4
14mm (6.5 - 8.0kg-m) 47.0 - 57.8 ft-lbs

12.5KW BTD

BOLTS 5,6,7,8,9,10,11,12,13 & 14
22mm (15 - 16kg-m) 108.4 - 115.7 ft-lbs

BOLTS 1,2,3 & 4
22mm (11 - 12kg-m) 79.0 - 86 ft-lbs



11.0KW BTD & 12.5KW BTDA

Rocker Shaft Holddown Bolts
14mm (4.0 - 5.5kg-m) 28.9 - 39.8 ft-lbs
10mm (0.8 - 1.2kg-m) 5.8 - 8.7 ft-lbs


12.5KW BTD

Rocker Shaft Holddown Bolts
14mm (4.0 - 5.5kg-m) 28.9 - 39.8 ft-lbs
10mm (0.8 - 1.2kg-m) 5.8 - 8.7 ft-lbs

NOTE: MM size shown are sockets size for holddown bolts.




VALVE CLEARANCE



TIMING MARK CRANKSHAFT PULLEY

Westerbeke recommends that these engine adjustments be made by a qualified mechanic.



CYLINDER HEAD BOLT TIGHTENING SEQUENCE

ENGINE ADJUSTMENTS

8.0KW & 10.0KW BTD

VALVE CLEARANCE ADJUSTMENT

Adjust the valve clearance when the engine is cold.
0.0098 inches (0.25 mm). Tighten the cylinder head bolts to the specified torque and sequence shown below.

1. Pull off the air breather pipe from the rocker cover, and take off the rocker cover bolts. Adjust the valve clearances at TDC (Top Dead Center) for each cylinder when they are on their compression stroke.
2. Align the timing marks on the gear case and on the crankshaft pulley as shown. In this position, the No.1 cylinder is at its Timing Mark while dead center on its compression stroke. Check both the intake and exhaust valve clearances of the cylinder. Of the valves have no specific clearance, adjust by means of adjusting screws. Remember to align the timing marks properly, if not the valve may be pushed up by the piston, depending on the position of the cam lobe.
3. Next, the piston of the No.3 cylinder comes TDC. Turn the crankshaft 240° clockwise from the above piston, aligning the timing mark of the crankshaft with that of the gear case. Then check and adjust the valve clearance.
4. To check the No.2 cylinders valve clearance, turn the crankshaft another 240° clockwise and then align the timing marks. Check and adjust the valve clearance in a similar manner.

NOTE: Retighten the cylinder head bolts before the valve clearance is adjusted.

MM size shown are sockets size for holddown bolts.

ROCKER SHAFT HOLDDOWN BOLTS



14mm (3.4 kg-m) 24.5 ft-lbs

8.0KW and 10.0KW BTD BOLTS #4,5,6,7,8,9,10 &11


17mm (11 - 12.5 KG-M) 83.2 - 90.4 ft-lbs

BOLTS # 1,2 & 3


14mm (6.5 - 8 kg-m) 47.0 - 57.9 ft-lbs



VALVE CLEARANCE



Westerbeke recommends that these engine adjustments be made by a qualified mechanic.



CYLINDER HEAD BOLT TIGHTENING SEQUENCE

SPECIFICATIONS WESTERBEKE 8.0 KW BTD GENERATOR

SPECIFICATIONS

Engine Type	Diesel, four-cycle, three-cylinder, fresh water-cooled, vertical in-line overhead valve mechanism, (14 hp at 1800 rpm maximum).
Governor	Mechanical, centrifugal weight type
Combustion Chamber	Swirl chamber type
Bore & Stroke	2.87 x 3.07 inches (73 x 78 mm)
Piston Displacement	60 cubic inches (0.979 liters)
Firing Order	1 - 3 - 2
Direction of Rotation	Clockwise, when viewed from the front
Maximum Torque (at 1800 rpm)	41.50 lb-ft (5.73 kg-m)
Compression Ratio	23:1
Compression Pressure	455.2 psi (32 kg/cm ²) at 280 rpm
Valve Timing	Intake Opens 18° BTDC Intake Closes 46° ABDC Exhaust Opens 46° BBDC Exhaust Closes 18° ATDC
Valve Seat Angle	Intake 45° Exhaust 45°
Valve Clearance (engine cold)	Intake 0.0098 inches (0.25 mm) Exhaust 0.0098 inches (0.25 mm)
Injection Pressure	1707 psi (120 kg/cm ² + 10 kg/cm ² - 0kg/cm ²)
Engine Speed	1800 rpm 60 Hertz 1500 rpm 50 Hertz
Engine Timing	19° BTDC
Dimensions	Height: 21.8 inches (552.72 mm) Width: 17.00 inches (431.80 mm) Length: 28.20 inches (716.28 mm)
Weight	450 lbs (204.12 kgs)
Fuel Consumption (approximate)	0.9 gph (3.40 lph) at full rated output
Inclination	Continuous 15° Temporary 20° (not to exceed 20 min.)

COOLING SYSTEM

General	Fresh water-cooled block, thermostatically-controlled with heat exchanger.
Operating Temperature	170 - 190° F (77 - 88° C).
Fresh Water Pump	Centrifugal type, metal impeller, belt-driven.
Raw Water Pump	Positive displacement, rubber impeller, belt-driven.
Raw Water Flow, at 1800 rpm	8.5 US gpm (32.2 lpm) (measured before discharging into exhaust elbow).
System Capacity (fresh water)	5.0 qts (4.73 liters).

FUEL SYSTEM

General	Open flow, self bleeding
Fuel	# 2 D(cetane rating of 45 or higher) SAE J313 Diesel grade according to ASTM D975
Fuel Injection Pump	Nippon Denso (Bosch M Type)
Fuel Injection Timing	19° ± .5° BTDC (static timing)
Nozzle	Throttle type
Injectors	Pintle Type
Fuel Pump	12 Volt DC, Electro-Magnetic type
Fuel Filter (on engine)	Canister type with replaceable element
Air cleaner	Metal screen type - cleanable
Air Flow	32 cfm (.906 cmm)

LUBRICATION SYSTEM

General	Pressure type by Trichoid pump, gear driven with external pressure relief valve
Oil Filter	Full flow, paper element, spin-on type.
Sump Capacity (not including filter)	3.3 U.S. quarts (3.12 liters).
Operating Oil Pressure (engine hot)	40 - 80 psi (2.8 - 5.6 kg/cm ²).
Oil Grade	API Specification CF, CG-4, CH-4, CI-4, CJ-4 or better SAE 10W-30 or 15W-40.

ELECTRICAL SYSTEM

Starting Battery	12-Volt, (-) negative ground
Battery Capacity	400 - 600 Cold Cranking Amps (CCA)
DC Charging Alternator	12 Volt DC, 50 Amp
Regulator	Internal regulator built into alternator
Starter	12-Volt, 1.2 KW, reduction, solenoid mounted
Starting Aid	Glow plugs, sheathed type
DC No-Load Current	90 Amps max. at 11.5 volts
DC Cranking Current	175-200 Amps (engine cold)

EXHAUST EMISSIONS SYSTEMS

Emission Control Systems	Smoke Puff Limiter
--------------------------	--------------------

SPECIFICATIONS

WESTERBEKE 8.0 KW BTD GENERATOR

AC GENERATOR	
General	Brushless, four-pole, revolving field. Pre-lubricated, single-bearing design. Reconnectable, single-phase transformer regulation (optional solid state voltage regulator)
Voltage	120 or 120/240 Volts - 60 Hertz 220 Volts - 50 Hertz.
Voltage Regulation	±5% no load to full load.
Frequency Regulation	±3 Hertz (5%) no load to full load.
Rating (Volts AC)	
60 Hertz (1800 rpm) 8.0 KW	120 Volts 66 Amps 120/240 Volts 66/33 Amps
50 Hertz (1500 rpm) 6.0 KW	220 Volts 27 Amps
Generator Cooling Air Requirements (60 Hertz) at 1800 rpm	175 - 200 cfm (5.66 - 6.37 cmm)
NOTE: Increase air supply 15% for 50 Hertz operation (1500 rpm).	

GENERATOR COOLING	
Engine Combustion Air Requirements (60 Hertz at 1800 RPM)	32 cfm (.906 cmm)
Generator Compartment Ambient Temperature Recommendations	104°F (40°C) maximum NOTE: Forced ventilation should be provided to maintain generator compartment temperatures below 104°F (40°C).
Cooling Air	100-200 cfm (2.83-5.66 cmm)

SPECIFICATIONS

WESTERBEKE 10.0 KW BTD GENERATOR

SPECIFICATIONS

Engine Type	Diesel, four-cycle, three-cylinder, fresh water-cooled, vertical in-line overhead valve mechanism, naturally aspirated (16.5 hp at 1800 rpm maximum).
Governor	Mechanical, centrifugal weight type
Combustion Chamber	Swirl chamber type
Bore & Stroke	3.07 x 3.07 inches (78 x 78 mm)
Piston Displacement	68 cubic inches (1.12 liters)
Firing Order	1 - 3 - 2
Direction of Rotation	Clockwise, when viewed from the front
Maximum Torque (at 1800 rpm)	47.7 lb-ft (6.6 kg-m)
Compression Ratio	23:1
Compression Pressure	483.5 psi (34 kg/cm ²) at 230 rpm
Valve Timing	Intake Opens 18° BTDC Intake Closes 45° ABDC Exhaust Opens 46° BBDC Exhaust Closes 18° ATDC
Valve Seat Angle	Intake 45° Exhaust 45°
Valve Clearance (engine cold)	Intake 0.0098 inches (0.25 mm) Exhaust 0.0098 inches (0.25 mm)
Injection Pressure	1707 psi (120 kg/cm ² + 10 kg/cm ² - 0kg/cm ²)
Engine Speed	1800 rpm 60 Hertz 1500 rpm 50 Hertz
Engine Timing	19° BTDC
Dimensions	Height: 22.0 inches (558.7 mm) Width: 16.85 inches (427.9 mm) Length: 32.56 inches (826.02 mm)
Weight	495 lbs (224.5 kgs)
Fuel Consumption (approximate)	1.0 gph (3.78 lph) at full rated output
Inclination	Continuous 15° Temporary 20° (not to exceed 20 min.)

COOLING SYSTEM

General	Fresh water-cooled block, thermostatically-controlled with heat exchanger.
Operating Temperature	170 - 190° F (77 - 88° C).
Fresh Water Pump	Centrifugal type, metal impeller, belt-driven.
Raw Water Pump	Positive displacement, rubber impeller, belt-driven.
Raw Water Flow, at 1800 rpm	7.2 US gpm (27.25 lpm) (measured before discharging into exhaust elbow).
System Capacity (fresh water)	8.0 qts (7.6 liters).

FUEL SYSTEM

General	Open flow, self bleeding
Fuel	# 2 D(cetane rating of 45 or higher) SAE J313 Diesel grade according to ASTM D975
Fuel Injection Pump	Nippon Denso (Bosch M Type)
Fuel Injection Timing	19° ± .5° BTDC (static timing)
Nozzle	Throttle type
Injectors	Pintle Type
Fuel Pump	12 Volt DC, Electro-Magnetic type
Fuel Filter (on engine)	Canister type with replaceable element
Air cleaner	Metal screen type - cleanable
Air Flow	48 cfm (1.36 cmm)
Fuel Lift Pump	12 Volt DC lift capacity 5' (1.5m)

LUBRICATION SYSTEM

General	Pressure type by Trichoid pump, gear driven with external pressure relief valve
Oil Filter	Full flow, paper element, spin-on type.
Sump Capacity (not including filter)	4.76 U.S. quarts (4.5 liters).
Operating Oil Pressure (engine hot)	40 - 80 psi (2.8 - 5. kg/cm ²).
Oil Grade	API Specification CF, CG-4, CH-4, CI-4, CJ-4 or better SAE 10W-30 or 15W-40.

ELECTRICAL SYSTEM

Starting Battery	12-Volt, (-) negative ground
Battery Capacity	400 - 600 Cold Cranking Amps (CCA)
DC Charging Alternator	12 Volt DC, 50 Amp
Regulator	Internal regulator built into alternator
Starter	12-Volt, 1.6 KW, reduction, solenoid mounted
Starting Aid	Glow plugs, sheathed type
DC No-Load Current	90 Amps max. at 11.5 volts
DC Cranking Current	175-200 Amps (engine cold)

EXHAUST EMISSIONS SYSTEMS

Emission Control Systems	Smoke Puff Limiter
--------------------------	--------------------

SPECIFICATIONS

WESTERBEKE 10.0 KW BTD GENERATOR

AC GENERATOR SINGLE PHASE

Single Phase	Brushless, four-pole, revolving field. Pre-lubricated, single-bearing design. Reconnectable, single-phase transformer regulation (optional solid state voltage regulator)	
Voltage	120 or 120/240 Volts - 60 Hertz 220 Volts - 50 Hertz.	
Voltage Regulation	±5% no load to full load.	
Frequency Regulation	±3 Hertz (5%) no load to full load.	
Rating (Volts AC)		
60 Hertz (1800 rpm) 10.0 KW	120 Volts	83.3 Amps
	120/240 Volts	83.3/41.6 Amps
50 Hertz (1500 rpm) 7.5 KW	220 Volts	34.1 Amps
Generator Cooling Air Requirements (60 Hertz) at 1800 rpm	225 - 250 cfm (5.66 - 6.37 cmm)	
NOTE: Increase air supply 15% for 50 Hertz operation (1500 rpm).		

AC GENERATOR THREE PHASE

Three Phase 10.0 KW - 60 Hertz 7.5 KW - 50 Hertz	Brushless, six-pole, revolving field. Sealed lubricated single bearing design. 12 lead reconnectable for low voltage WYE, high voltage Delta. Solid state voltage regulator with protection circuitry.	
Voltage - 3 Phase (60 Hertz)	Low voltage WYE	208 volts
	High voltage WYE	480 volts
	DELTA	240 volts
Voltage - 3 Phase (50 Hertz)	High voltage WYE	380 volts
	DELTA	220 volts
Amperage - 3 Phase (60 Hertz)	Low voltage WYE	35 Amps
	High voltage WYE	15 Amps
	DELTA	30 Amps
Amperage - 3 Phase (50 Hertz)	High voltage WYE	14 Amps
	DELTA	24 Amps

GENERATOR COOLING

Engine Combustion Air Requirements (60 Hertz at 1800 RPM)	32 cfm (.906 cmm)
Generator Compartment Ambient Temperature Recommendations	104°F (40°C) maximum
	NOTE: Forced ventilation should be provided to maintain generator compartment temperatures below 104°F (40°C).
Cooling Air	100-200 cfm (2.83-5.66 cmm)

SPECIFICATIONS WESTERBEKE 11.0 KW BTD GENERATOR

SPECIFICATIONS

Engine Type	Diesel, four-cycle, three-cylinder, fresh water-cooled, vertical in-line overhead valve mechanism, (18.4 hp at 1800 rpm maximum).
Governor	Mechanical, centrifugal weight type
Combustion Chamber	Swirl chamber type
Bore & Stroke	2.87 x 3.07 inches (73 x 78 mm)
Piston Displacement	80 cubic inches (1.305 liters)
Firing Order	1 - 3 - 4 - 2
Direction of Rotation	Clockwise, when viewed from the front
Maximum Torque (at 1800 rpm)	54 lb-ft (7.46 kg-m)
Compression Ratio	23:1
Compression Pressure	455 psi (32 kg/cm ²) at 280 rpm
Valve Timing	Intake Opens 18° BTDC Intake Closes 46° ABDC Exhaust Opens 46° BBDC Exhaust Closes 18° ATDC
Valve Seat Angle	Intake 45° Exhaust 45°
Valve Clearance (engine cold)	Intake 0.0098 inches (0.25 mm) Exhaust 0.0098 inches (0.25 mm)
Injection Pressure	1707 psi (120 kg/cm ² + 10 kg/cm ² - 0kg/cm ²)
Engine Speed	1800 rpm 60 Hertz 1500 rpm 50 Hertz
Engine Timing	19° BTDC
Dimensions	Height: 23.75 inches (603.25 mm) Width: 16.85 inches (427.99 mm) Length: 34.56 inches (877.82 mm)
Weight	575 lbs (260.8 kgs)
Fuel Consumption (approximate)	1.2 gph (4.54 lph) at full rated output
Inclination	Continuous 15° Temporary 20° (not to exceed 20 min.)

COOLING SYSTEM

General	Fresh water-cooled block, thermostatically-controlled with heat exchanger.
Operating Temperature	170° - 190° F (77° - 88° C).
Fresh Water Pump	Centrifugal type, metal impeller, belt-driven.
Raw Water Pump	Positive displacement, rubber impeller, belt-driven.
Raw Water Flow, at 1800 rpm	7.2 US gpm (27.25 lpm) (measured before discharging into exhaust elbow).
System Capacity (fresh water)	8 qts (7.6 liters).

FUEL SYSTEM

General	Open flow, self bleeding
Fuel	# 2 D (cetane rating of 45 or higher) SAE J313 Diesel grade according to ASTM D975
Fuel Injection Pump	Nippon Denso (Bosch M Type)
Fuel Injection Timing	19° ± .5° BTDC (static timing)
Nozzle	Throttle type
Injectors	Pintle Type
Fuel Pump	12 Volt DC, Electro-Magnetic type
Fuel Filter (on engine)	Canister type with replaceable element
Air cleaner	Metal screen type - cleanable
Air Flow	42 cfm (1.2 cmm)

LUBRICATION SYSTEM

General	Pressure type by Trichoid pump, gear driven with external pressure relief valve
Oil Filter	Full flow, paper element, spin-on type.
Sump Capacity (not including filter)	4.23 U.S. quarts (4.0 liters).
Operating Oil Pressure (engine hot)	40 - 80 psi (2.8 - 5.6 kg/cm ²).
Oil Grade	API Specification CF, CG-4, CH-4, CI-4, CJ-4 or better SAE 10W-30 or 15W-40.

ELECTRICAL SYSTEM

Starting Battery	12-Volt, (-) negative ground
Battery Capacity	400 - 600 Cold Cranking Amps (CCA)
DC Charging Alternator	12 Volt DC, 50 Amp
Regulator	Internal regulator built into alternator
Starter	12-Volt, 1.6 KW, reduction, solenoid mounted
Starting Aid	Glow plugs, sheathed type
DC No-Load Current	90 Amps max. at 11.5 volts
DC Cranking Current	175-200 Amps (engine cold)

EXHAUST EMISSIONS SYSTEMS

Emission Control Systems	Smoke Puff Limiter
--------------------------	--------------------

SPECIFICATIONS

WESTERBEKE 11.0 KW BTD GENERATOR

AC GENERATOR SINGLE PHASE

Single Phase	Brushless, four-pole, revolving field. Pre-lubricated, single-bearing design. Reconnectable, single-phase transformer regulation (optional solid state voltage regulator)	
Voltage	120 or 120/240 Volts - 60 Hertz 220 Volts - 50 Hertz.	
Voltage Regulation	±5% no load to full load.	
Frequency Regulation	±3 Hertz (5%) no load to full load.	
Rating (Volts AC)		
60 Hertz (1800 rpm) 11.0 KW	120 Volts	91.6Amps
	120/240 Volts	91.6/45.8 Amps
50 Hertz (1500 rpm) 8.3 KW	220 Volts	37.7 Amps
Generator Cooling Air Requirements (60 Hertz) at 1800 rpm	200 - 225 cfm (5.66 - 6.37 cmm)	

NOTE: Increase air supply 15% for 50 Hertz operation (1500 rpm).

AC GENERATOR THREE PHASE

Three Phase 11.0 KW - 60 Hertz 8.3 KW - 50 Hertz	Brushless, six-pole, revolving field. Sealed lubricated single bearing design. 12 lead reconnectable for low voltage WYE, high voltage Delta. Solid state voltage regulator with protection circuitry.	
Voltage - 3 Phase (60 Hertz)	Low voltage WYE	208 volts
	High voltage WYE	480 volts
	DELTA	240 volts
Voltage - 3 Phase (50 Hertz)	High voltage WYE	380 volts
	DELTA	220 volts
Amperage - 3 Phase (60 Hertz)	Low voltage WYE	38 Amps
	High voltage WYE	16 Amps
	DELTA	33 Amps
Amperage - 3 Phase (50 Hertz)	High voltage WYE	15 Amps
	DELTA	27 Amps

GENERATOR COOLING

Engine Combustion Air Requirements (60 Hertz at 1800 RPM)	32 cfm (.906 cmm)
Generator Compartment Ambient Temperature Recommendations	104°F (40°C) maximum
	NOTE: Forced ventilation should be provided to maintain generator compartment temperatures below 104°F (40°C).
Cooling Air	100-200 cfm (2.83-5.66 cmm)

SPECIFICATIONS

WESTERBEKE 12.5 KW BTD(A) GENERATOR

SPECIFICATIONS

Engine Type	Diesel, four-cycle, three-cylinder, fresh water-cooled, vertical in-line overhead valve mechanism, (23 hp at 1800 rpm maximum).
Governor	Mechanical, centrifugal weight type
Combustion Chamber	Swirl chamber type
Bore & Stroke	3.07 x 3.07 inches (78 x 78 mm)
Piston Displacement	91 cubic inches (1.49 liters)
Firing Order	1 - 3 - 4 - 2
Direction of Rotation	Clockwise, when viewed from the front
Maximum Torque (at 1800 rpm)	67 lb-ft (9.26 kg-m)
Compression Ratio	23:1
Compression Pressure	455 psi (32 kg/cm ²) at 280 rpm
Valve Timing	Intake Opens 20° BTDC Intake Closes 44° ABDC Exhaust Opens 44° BBDC Exhaust Closes 20° ATDC
Valve Seat Angle	Intake 45° Exhaust 45°
Valve Clearance (engine cold)	Intake 0.0098 inches (0.25 mm) Exhaust 0.0098 inches (0.25 mm)
Injection Pressure	1707 psi (120 kg/cm ² + 10 kg/cm ² - 0kg/cm ²)
Engine Speed	1800 rpm 60 Hertz 1500 rpm 50 Hertz
Engine Timing	19° BTDC
Dimensions	Height: 25.34 inches (643.60 mm) Width: 18.17 inches (461.50 mm) Length: 37.25 inches (946.10 mm)
Weight	638 lbs (289.4 kgs)
Fuel Consumption (approximate)	1.4 gph (5.29 lph) at full rated output
Inclination	Continuous 15° Temporary 20° (not to exceed 20 min.)

COOLING SYSTEM

General	Fresh water-cooled block, thermostatically-controlled with heat exchanger.
Operating Temperature	170° - 190° F (77° - 88° C).
Fresh Water Pump	Centrifugal type, metal impeller, belt-driven.
Raw Water Pump	Positive displacement, rubber impeller, belt-driven.
Raw Water Flow, at 1800 rpm	7.2 US gpm (27.25 lpm) (measured before discharging into exhaust elbow).
System Capacity (fresh water)	8 qts (7.6 liters).

FUEL SYSTEM

General	Open flow, self bleeding
Fuel	# 2 D (cetane rating of 45 or higher) SAE J313 Diesel grade according to ASTM D975
Fuel Injection Pump	Nippon Denso (Bosch M Type)
Fuel Injection Timing	19° ± .5° BTDC (static timing)
Nozzle	Throttle type
Injectors	Pintle Type
Fuel Pump	12 Volt DC, Electro-Magnetic type
Fuel Filter (on engine)	Canister type with replaceable element
Air cleaner	Metal screen type - cleanable
Air Flow	48 cfm (1.2 cmm)

LUBRICATION SYSTEM

General	Pressure type by Trichoid pump, gear driven with external pressure relief valve
Oil Filter	Full flow, paper element, spin-on type.
Sump Capacity (not including filter)	4.76 U.S. quarts (4.5 liters).
Operating Oil Pressure (engine hot)	40 - 80 psi (2.8 - 5.6 kg/cm ²).
Oil Grade	API Specification CF, CG-4, CH-4, CI-4, CJ-4 or better SAE 10W-30 or 15W-40.

ELECTRICAL SYSTEM

Starting Battery	12-Volt, (-) negative ground
Battery Capacity	400 - 600 Cold Cranking Amps (CCA)
DC Charging Alternator	12 Volt DC, 50 Amp
Regulator	Internal regulator built into alternator
Starter	12-Volt, 1.6 KW, reduction, solenoid mounted
Starting Aid	Glow plugs, sheathed type
DC No-Load Current	90 Amps max. at 11.5 volts
DC Cranking Current	175-200 Amps (engine cold)

EXHAUST EMISSIONS SYSTEMS

Emission Control Systems	Smoke Puff Limiter
--------------------------	--------------------

SPECIFICATIONS

WESTERBEKE 12.5 KW BTD(A) GENERATOR

AC GENERATOR SINGLE PHASE	
Single Phase	Brushless, four-pole, revolving field. Pre-lubricated, single-bearing design. Reconnectable, single-phase transformer regulation (optional solid state voltage regulator)
Voltage	120 or 120/240 Volts - 60 Hertz 220 Volts - 50 Hertz.
Voltage Regulation	±5% no load to full load.
Frequency Regulation	±3 Hertz (5%) no load to full load.
Rating (Volts AC)	
60 Hertz (1800 rpm) 12.5 KW	120 Volts 104 Amps 120/240 Volts 104/52 Amps
50 Hertz (1500 rpm) 9.3 KW	220 Volts 42.3 Amps
Generator Cooling Air Requirements (60 Hertz) at 1800 rpm	200 - 255 cfm (6.37 - 7.08 cmm)
NOTE: Increase air supply 15% for 50 Hertz operation (1500 rpm).	

AC GENERATOR THREE PHASE		
Three Phase 12.5 KW - 60 Hertz 9.3 KW - 50 Hertz	Brushless, six-pole, revolving field. Sealed lubricated single bearing design. 12 lead reconnectable for low voltage WYE, high voltage Delta. Solid state voltage regulator with protection circuitry.	
Voltage - 3 Phase (60 Hertz)	Low voltage WYE High voltage WYE DELTA	208 volts 480 volts 240 volts
Voltage - 3 Phase (50 Hertz)	High voltage WYE DELTA	380 volts 220 volts
Amperage - 3 Phase (60 Hertz)	Low voltage WYE High voltage WYE DELTA	43 Amps 18 Amps 37 Amps
Amperage - 3 Phase (50 Hertz)	High voltage WYE DELTA	17 Amps 30 Amps
GENERATOR COOLING		
Engine Combustion Air Requirements (60 Hertz at 1800 RPM)	32 cfm (.906 cmm)	
Generator Compartment Ambient Temperature Recommendations	104°F (40°C) maximum NOTE: Forced ventilation should be provided to maintain generator compartment temperatures below 104°F (40°C).	
Cooling Air	100-200 cfm (2.83-5.66 cmm)	

GENERATOR INFORMATION

USE OF ELECTRIC MOTORS

The power required to start an electric motor is considerably more than is required to keep it running after it is started. Some motors require much more current to start them than others. Split-phase (AC) motors require more current to start, under similar circumstances, than other types. They are commonly used on easy-starting loads, such as washing machines; or where loads are applied after the motor is started, such as small power tools. Because they require 5 to 7 times as much current to start as to run, their use should be avoided, whenever possible, if the electric motor is to be driven by a small generator. Capacitor and repulsion-induction motors require from 2 to 4 times as much current to start as to run. The current required to start any motor varies with the load connected to it. An electric motor connected to an air compressor, for example, will require more current than a motor to which no load is connected.

In general, the current required to start 115-Volt motors connected to medium starting loads will be approximately as follows:

MOTOR SIZE (HP)	AMPS FOR RUNNING (AMPERES)	AMPS FOR STARTING (AMPERES)
1/6	3.2	6.4 to 22.4*
1/4	4.6	9.2 to 32.2*
1/3	5.2	10.4 to 72.8*
1/2	7.2	14.4 to 29.2*
3/4	10.2	20.4 to 40.8*
1	13	26 to 52

***NOTE:** In the above table the maximum Amps for Starting is more for some small motors than for larger ones. The reason for this is that the hardest starting types (split-phase) are not made in larger sizes.

Because the heavy surge of current needed for starting motors is required for only an instant, the generator will not be damaged if it can bring the motor up to speed in a few seconds. If difficulty is experienced in starting motors, turn off all other electrical loads and, if possible, reduce the load on the electric motor.

Required Operating Speed

Run the generator first with no load applied, then at half the generator's capacity, and finally loaded to its full capacity as indicated on the generator's data plate. The output voltage should be checked periodically to ensure proper operation of the generating plant and the appliances it supplies. If an AC voltmeter or ampere meter is not installed to monitor voltage and load, check it with a portable meter and amp probe.

NOTE: When the vessel in which the generator is installed contains AC equipment of 120 volts only, it is recommended that the generator's AC terminal block be configured to provide one 120 volt AC hot leg for the vessel's distribution panel. This will ensure good motor starting response from the generator.

Generator Frequency Adjustment

Frequency is a direct result of engine/generator speed, as indicated by the following:

- When the generator is run at 1800 RPM, the AC voltage output frequency is 60 Hertz.
- When the generator is run at 1500 RPM, the AC voltage output frequency is 50 Hertz.

Therefore, to change the generator's frequency, the generator's drive engine's speed must be changed. A reconfiguration of the AC output connections at the generator is also necessary.

Generator Maintenance

- Maintaining reasonable cleanliness is important. Connections of terminal boards and rectifiers may become corroded, and insulation surfaces may start conducting if salts, dust, engine exhaust, carbon, etc. are allowed to build up. Clogged ventilation openings may cause excessive heating and reduced life of windings.
- For unusually severe conditions, thin rust-inhibiting petroleum-base coatings, should be sprayed or brushed over all surfaces to reduce rusting and corrosion. Typical materials suggested are Daubert Chemical Co. "Non-Rust AC-410" and Ashland "Tectyle 506" or equivalent.
- In addition to periodic cleaning, the generator should be inspected for (a) tightness of all connections, (b) evidence of overheated terminals and (c) loose or damaged wires.
- The drive discs on single bearing generators should be checked periodically if possible for tightness of screws and for any evidence of incipient cracking failure. Discs should not be allowed to become rusty because rust may accelerate cracking. The bolts which fasten the drive disc to the generator shaft must be hardened steel SAE grade 8, identified by 6 radial marks, one at each of the 6 corners of the head.
- The rear armature bearing is lubricated and sealed; no maintenance is required. However, if the bearing becomes noisy or rough-sounding, have it replaced.
- Examine bearing at periodic intervals. No side movement of shaft should be detected when force is applied. If side motion is detectable, bearings are wearing or wear on shaft of bearing socket outside bearing has occurred. Repair must be made quickly or major components will rub and cause major damage to generator.



The generator's data plate gives the voltage, current, and frequency rating of the generator. An AC wiring decal is on the inside of the louvered cover at the generator end that includes the AC voltage connections. These voltage diagrams are also shown on these pages.

BT GENERATOR

This generator is a four-pole, brushless, self-excited generator which requires only the driving force of the engine to produce AC output. The copper and laminated iron in the exciter stator are responsible for the self-exciting feature of this generator. The magnetic field produced causes an AC voltage to be induced into the related exciter rotor windings during rotation. Diodes located in the exciter rotor rectify this voltage to DC and supply it to the windings of the rotating field. This creates an electromagnetic field which rotates through the windings of the main stator, inducing an AC voltage which is supplied to a load. A step down transformer is connected in parallel to the AC output of the main stator. An AC voltage is produced in the auxiliary windings of the transformer and the main stator and is, in turn, supplied to a full-wave bridge rectifier. The rectifier produces a DC voltage to further excite the exciter stator windings, enabling the generator to produce a rated AC output. An optional solid-state voltage regulator is available to work in tandem with the transformer regulator to produce a more stable AC output.

A circuit breaker is installed on all WESTERBEKE generators. This circuit breaker will automatically disconnect generator power in case of an electrical overload. The circuit breaker can be manually shut off when servicing the generator to ensure no power is coming into the boat.

NOTE: This circuit breaker is available as a WESTERBEKE add-on kit for earlier model generations; contact your WESTERBEKE dealer.



BT GENERATOR SINGLE PHASE

OPTIONAL AUTOMATIC VOLTAGE REGULATOR (AVR) BT 6 STUD MODELS ONLY

An optional solid-state voltage regulator (board #34410) is available for use with the BT series generators. When installed, and the regulation switch is moved to the ELEC position, the regulator works together with the standard compound transformer regulator to regulate the generator's voltage output. In the ELEC mode, the regulator provides excitation to the group 1 exciter windings, and the transformer provides excitation to the group 2 exciter windings.

Installation

1. The regulator is mounted using existing tapped holes in the generator's case. Use two (2) M4 x 0.7mm screws, each 15mm long, with lock washers to mount the regulator board.
2. Connect the 6-prong generator plug to the receptacle on the regulator board.

NOTE: The plug is keyed to engage the regulator receptacle in one direction. Check this and insert it correctly.

3. Before moving the selector switch to the ELEC position, the NO-Load voltage produced by the generator when in the COMP position will have to be adjusted. The NO-Load voltage should be adjusted down between 114 - 118 volts (60Hz) or 224 - 228 volts (50Hz) following the procedures as explained earlier in this manual.
4. With the generators no load voltage properly adjusted, move the selection switch into the ELEC position. Adjust the regulator board potentiometer to set NO-Load voltage at 120 - 122 volts at 61.5 - 62.0 Hertz (230 - 234 volts at 51.5 - 52.0 Hertz). The regulator board is operating in parallel with the compound transformer and should maintain voltage output within ± 5 per cent from NO-Load to FULL-Load.

NOTE: Do not use the regulator to force NO-Load voltage down. Use the compound transformer for this function. Using the regulator to perform this causes the regulator to use more exciter circuit power. This leaves less exciter circuit power for loaded conditions.

Switching Shore Power to Generator Power

CAUTION: Heavy motor leads should be shut off before switching shore power to generator power or vice-versa because voltage surges induced by switching with heavy AC loads on the vessel being operated may cause damage to the exciter circuit components in the generator.

BT GENERATOR TROUBLESHOOTING CHART

NOTE: WESTERBEKE recommends that the following generator tests and adjustments be performed by a qualified technician.

LOW VOLTAGE 60-100 VOLTS AC COMPONENT CHECKS:

- F SELECTOR SWITCH (6 Stud Models)
- B ROTOR COMPONENTS
 - B2. EXCITER ROTOR DIODES
 - B3. ROTOR FIELD WINDING
 - B1. EXCITER ROTOR WINDING(S) a,b,c.
- A 1-1+2 EXCITER STATOR WINDING(S).


NO AC VOLTAGE OUTPUT MAIN STATOR, ROTOR COMPONENTS, TRANSFORMER COMPONENT CHECKS:

- C 1+2 MAIN STATOR WINDING
- B 4 POSI RESISTOR
- B 2 DIODES (4-6 OPEN/SHORTED)
- D 1+2 COMPOUND TRANSFORMER WINDING
- B 3 ROTOR FIELD WINDING

RESIDUAL VOLTAGE EXCITER CIRCUIT FAULTY COMPONENT CHECKS:

- A 1-1+2 EXCITER STATOR WINDING(S)
 - G BRIDGE RECTIFIER
 - D 3 TRANSFORMER AUX. WINDING
 - C 3 MAIN STATOR AUX. WINDING
 - F SELECTOR SWITCH
- CIRCUIT CONNECTIONS (from the Transformer Aux. winding to the connections on the Bridge Rectifier)

INTERNAL WIRING SCHEMATIC (12 STUD) BT GENERATOR



COMPONENT RESISTANCE (IN OHMS)

A EXCITER STATOR WINDINGS

1....10.0 Ω

B AUXILIARY ROTOR WINDINGS

1 a b c Auxiliary Windings are measured in pairs:
a-b....1.3 Ω , b-c....1.3 Ω , c-a....1.3 Ω

2 Diodes (6).... Ω /infinite

3 Rotating Field Windings....8.1 Ω

4 Thermister....infinite

C MAIN STATOR WINDINGS

1 and 2....0.6 Ω

3 Main Stator Auxiliary Windings....1.8 Ω

D COMPOUND TRANSFORMER WINDINGS

1 and 2....0.2 Ω

3 Compound Transformer Aux. Windings...4.3 Ω

G BRIDGE RECTIFIER

Note: Resistance readings and voltage checks can be accessed easily for the components in the exciter circuit A, G, C-3 and D-3 by locating the color coded wires at the connection points shown on the above schematic. When checking winding resistance values be sure to lift both of the component's electrical connections.

EXCITER CIRCUIT VOLTAGES (NOMINAL)

AC into Bridge Rectifier: No Load 16 VAC - Full Load 45 VAC

DC out of Bridge Rectifier: No Load 7 VDC - Full Load 20 VDC

NOTE: A illustrated booklet for the 6 & 12 Stud BT generators (AC Electrical Testing, Adjustments and Troubleshooting) is available in pdf form to download off our website www.westerbeke.com

GENERATOR VOLTAGE ADJUSTMENT

NOTE: WESTERBEKE recommends that the following generator tests and adjustments be performed by a qualified technician.

NO-LOAD VOLTAGE ADJUSTMENT

Voltage adjustment is made with the generator regulation being governed by the compound transformer.

1. The selector switch, if installed, *must* be in the COMP position.
2. To confirm no-load voltage, start the generator and apply a momentary (moderate) load to excite the transformer. The voltage produced by the generator after the momentary load is removed is no-load voltage. Note the voltage output from the generators 120 volt leg(s) (230 volt 50 hertz). The no-load voltage should be between 121-124 volts at 61.5-62 hertz (232- 236 volts at 51.5-52 hertz).

NOTE: The no-load voltage should be adjusted to the voltage produced by the generator once started and a momentary load should be applied to excite the transformer and then removed. The voltage produced by the generator after this momentary load is removed is no-load voltage.

3. To raise or lower the voltage, shims of varying thickness (non-conductive material) are placed or removed from under the steel laminated bar on top of the compound transformer. The material used for shimming should not soften at temperatures in the 176° F (80° C) range. A small reduction in no-load voltage (1 to 3 volts) can some times be accomplished by gently tapping the top of the laminated steel bar to reduce the gap between the existing shims and the transformer core.

NOTE: No-load voltage may be effected needing readjustment with the compound transformer. Do not use these adjustments to compensate for overload conditions being placed on the generator/engine (inductive-motor type loads). Loss of generator hertz/speed, the result of overload, will cause a drop in voltage output.


Shim thickness of 0.001 inch will change the no-load voltage by approximately 4 - 6 volts. Adding shim material raises the no-load voltage. Removing shim material lowers no-load voltage.

FULL-LOAD VOLTAGE ADJUSTMENT

The voltage hertz connection bar that is used when changing from 60Hz to 50Hz can also be used to increase or decrease the generators full-load output.

Fine voltage adjustments can be performed by repositioning wires **A** to leads #1, #2, and #3 increasing the loaded voltage progressively in that order. A no-load voltage adjustment will have to be made as well.

Should full-load output fall below 108 volts-60Hz (210 volts-50Hz), the voltage should be adjusted.



NOTE: When the optional voltage regulator is installed and if the Blue/White (Blue) lead is not correctly positioned to correspond to the Hertz the unit is operating at, the regulator will sense incorrect voltage and cause the generator to produce abnormally high output voltage.

GENERATOR VOLTAGE ADJUSTMENT

NOTE: WESTERBEKE recommends that the following generator tests and adjustments be performed by a qualified technician.

Generator Frequency

1. Frequency is a direct result of engine/generator speed:
1800 rpm = 60 hertz
1500 rpm = 50 hertz.
2. To change generator frequency follow the steps below.
 - a. Connect the AC output leads to the AC terminal block, following the illustrations on this page.
 - b. If an AVR is installed, reposition the blue or blue/white lead to correspond to the hertz selected on the Voltage/Hertz Connection Bar.

If there is no automatic voltage regulator (AVR) installed, do not change the wiring on the Voltage/Hertz Connection Bar. Simply reconfigure the AC terminal for the hertz change.

- c. Start the engine, monitor voltage and adjust engine no-load speed. Adjust diesel units by the linkage between the throttle arm and fuel solenoid or the throttle lever on the injection pump..
60 hertz: no-load speed, 61.5 - 62.0 hertz.
50 hertz: no-load speed, 51.5 - 52.0 hertz.

- d. After the no-load hertz adjustment is made, the no-load voltage may need to be readjusted. In most cases, if the generator was producing the correct no-load voltage at the previous hertz setting, it would be correct at the changed hertz setting.

In the event it needs adjustment, adjust the shim thickness under the laminated steel bar of the transformer.

- 60 hertz: no-load voltage, 121-124 volts.
50 hertz: no-load voltage, 232-236 volts.

- e. Load the generator to the rated amperage output corresponding to the hertz speed of the generator.
Rated Loaded Speed

60 hertz: loaded speed, 58.5 - 59.0 hertz


50 hertz: loaded speed, 48.5 - 49.0 hertz

The lowest acceptable voltage at full rated output (amps)


60 hertz: 108 - 110 volts

50 hertz: 205 - 210 volts

SIX STUD AC VOLTAGE CONNECTIONS




TWELVE STUD AC VOLTAGE CONNECTIONS



The frame ground wire must be moved when changing from 115 volts and 110/220 volts 50 hertz to 230 volts 50 hertz. From making connections to the AC terminal block, use terminal ends for 1/4 inch studs that will accept multi-strand copper wire sized for the amperage rating from the hot lead connection. The frame ground wire is white or white with a green strip. It connects between the neutral stud and the generator frame.

INTERNAL WIRING SCHEMATIC (6 STUD) BT GENERATOR W/OPTIONAL VOLTAGE REGULATOR



COMPONENT RESISTANCE (IN OHMS)

A EXCITER STATOR WINDINGS

- 1 and 2....11.5 Ω
- 1....49.4 Ω
- 2....12.9 Ω

B EXCITER ROTOR AND FIELD WINDINGS

- 1 a b c auxiliary windings are measured in pairs:
a-b...1.5 Ω, b-c...1.5 Ω, c-a...1.5 Ω
- 2 Diodes (6)....Ω/Infinite
- 3 Rotor Field Windings....9.7 Ω
- 4 Thermister....Infinite

C MAIN STATOR WINDINGS

- 1 and 2....0.4 Ω
- 3 Main Stator Aux. Windings....1.3 Ω

D COMPOUND TRANSFORMER WINDINGS

- 1 and 2....0.4 Ω
- Compound Transformer Aux. Windings 3.... 4.3 Ω

- E Voltage Regulator (optional)
- F Selector Switch
- G Bridge Rectifier

Note: Resistance readings and voltage checks can be accessed easily for the components in the exciter circuit A, G, C-3 and D-3 by locating the color coded wires at the connection points shown on the above schematic. When checking winding resistance values be sure to lift both of the component's electrical connections.


EXCITER CIRCUIT VOLTAGES (NOMINAL)

Voltages measured across the AC and DC connections on the Bridge Rectifier

AC into Bridge Rectifier: No Load 20 VAC - Full Load 55 VAC

DC out of Bridge Rectifier: No Load 8 VDC - Full Load 18 VDC

BT GENERATOR INTERNAL WIRING 3 PHASE TWELVE WIRE RECONNECTABLE



AUX. AC VOLTAGES


N/L 183 - 184

F/L 189 - 190

EXCITER DC VOLTAGES

N/L 8.5 - 9.0

F/L 15 - 16




GENERATOR AC VOLTAGE CONNECTIONS BE THREE PHASE


VOLTAGE REGULATORS THREE PHASE CONNECTIONS

The regulator is equipped with seven numbered terminals (0 to 6) and their related brass jumpers. The illustrations shown connection points and jumpers for the 3 phase configuration of the generator. The sensing leads connect between pin #1 and pin #2 on the AC terminal block and connection #2 and #0 on the voltage regulator board.

NOTE: Either Series configuration requires the installation of a jumper on the regulator board between terminal B and O.




AC TERMINAL CONNECTIONS THREE PHASE 12 WIRE




PARALLEL WYE (STAR)

L - N - 120 VAC	1Ø	60 HZ	L - L - 208 VAC	3Ø	60 HZ
L - N - 115 VAC	1Ø	50 HZ	L - L - 190 VAC	3Ø	50 HZ



SERIES WYE (STAR)



L - L - 480 VAC	3Ø	60 HZ	L - L - 400 VAC	3Ø	50 HZ
L - N - 277 VAC	1Ø	60 HZ	L - N - 230 VAC	3Ø	50 HZ



SERIES DELTA

L - N - 240 VAC	3Ø	60 HZ	L - N - 230 VAC	3Ø	50 HZ
L2, L3 - N - 120 VAC	1Ø	60 HZ	L2, L3 - N - 115 VAC	1Ø	50 HZ

SHORE POWER TRANSFER SWITCH



230 VOLT/50 HZ TWO WIRE CONFIGURATION

SHORE POWER CONNECTIONS (60 HERTZ)

If the installer connects shore power to the vessel's AC circuit, this must be done by means of the Shore Power Transfer Switch. Set the transfer switch shown in the diagrams to the OFF position. This switch prevents simultaneous connection of shore power to generator output.


CAUTION: Damage to the generator can result if utility shore power and generator output are connected at the same time. This type of generator damage is not covered under the warranty; it is the installer's responsibility to make sure all AC connections are correct.

Switching Shore Power to Generator Power

CAUTION: Heavy motor loads should be shut off before switching shore power to generator power or vice-versa because voltage surges induced by switching with heavy AC loads on the vessel being operated may cause damage to the exciter circuit components in the generator.


120 VOLT/60 HZ THREE WIRE CONFIGURATION

Notice the repositioning of the white wire ground load on the terminal block to the generator case.




WIRING DIAGRAM #34651

(8 BTD)




WIRING DIAGRAM #36412

(NO RELAYS)




An on-off switch should be installed in this circuit to disconnect the starter from the battery in an emergency and when leaving the boat. Twelve volt diesel engine starters typically draw 200 to 300 amps when cranking. A switch with a continuous rating of 175 amps at 12 VDC will normally serve this function, but a switch must never be used to "make" the starter circuit.



WIRING SCHEMATIC #36412

(NO RELAYS)



STARTING AND STOPPING INSTRUCTIONS


- START:**
1. ALWAYS PUSH PREHEAT SWITCH FIRST. HOLD FOR 15 TO 60 SECONDS AS REQ'D.
 2. WHILE CONTINUING TO PUSH PREHEAT SWITCH, PUSH START SWITCH.
 3. WHEN GENERATOR STARTS, RELEASE START SWITCH ONLY.
 4. WHEN OIL PRESSURE REACHES APPROXIMATELY 20 PSI, RELEASE PREHEAT SWITCH (THE PREHEAT SWITCH OVERRIDES THE LOW OIL PRESSURE SHUT-DOWN CIRCUIT).
- STOP:** PUSH AND HOLD THE STOP SWITCH UNTIL THE GENERATOR STOPS COMPLETELY.

NOTES:



1. THIS PRODUCT IS PROTECTED BY A MANUAL RESET CIRCUIT BREAKER LOCATED NEAR THE STARTER AND AS CLOSE TO THE SOURCE OF CURRENT AS POSSIBLE. EXCESSIVE CURRENT DRAW ANYWHERE IN THE INSTRUMENT PANEL, WIRING OR ENGINE WILL CAUSE THE BREAKER TO TRIP. IN THIS EVENT MOST GENERATORS WILL SHUT DOWN BECAUSE THE OPENED BREAKER DISCONNECTS THE FUEL SUPPLY. THEREFORE THE BUILDER/OWNER MUST BE SURE THAT THE INSTRUMENT PANEL, WIRING AND ENGINE ARE INSTALLED TO PREVENT CONTACT BETWEEN ELECTRICAL DEVICES AND SALT WATER.
2. AN ON-OFF SWITCH SHOULD BE INSTALLED IN THIS CIRCUIT TO DISCONNECT THE STARTER FROM THE BATTERY IN AN EMERGENCY AND WHEN LEAVING THE BOAT. TWELVE VOLT DIESEL ENGINE STARTERS TYPICALLY DRAW 200 TO 300 AMPS WHEN CRANKING. THE DURATION OF INDIVIDUAL CRANKING CYCLES SHOULD NOT EXCEED 30 SECONDS. A SWITCH WITH A CONTINUOUS RATING OF 175 AMPS AT 12VDC WILL NORMALLY SERVE THIS FUNCTION, BUT A SWITCH MUST NEVER BE USED TO "MAKE" THE STARTER CIRCUIT.

WIRING DIAGRAM #36412


(TWO RELAYS)





WIRING DIAGRAM BTD & BTDA (24V) #41479




WIRING SCHEMATIC BTD & BTDA (24V) #41479




WIRING DIAGRAM BTD & BTDA #43853



WIRING SCHEMATIC BTD & BTDA #43853



WIRING SCHEMATIC BTDA #43944



(OPTIONAL)
REMOTE OIL FILTER (OPTIONAL)

PN.040078

INSTALLATION

This popular accessory is used to relocate the engine's oil filter from the engine to a more convenient location such as an engine room bulkhead.

NOTE: Refer to *ENGINE OIL CHANGE* in this manual for instructions on removing the oil filter.


To install, simply remove the engine oil filter and thread on WESTERBEKE'S remote oil filter kit as shown. Always install this kit with the oil filter facing down as illustrated.

Contact your WESTERBEKE dealer for more information.

NOTE: Westerbeke is not responsible for engine failure due to incorrect installation of the Remote Oil Filter.

CAUTION: It is vital to install the oil lines correctly. If the oil flows in the reverse direction, the by-pass valve in the filter assembly will prevent the oil from reaching the engine causing an internal engine failure. If there is no oil pressure reading, shutdown immediately and check the hose connections

APPLY A THIN COAT OF CLEAN OIL TO THE O-RING WHEN INSTALLING THIS KIT. THREAD THE KIT ON, THEN HAND TIGHTEN AN ADDITIONAL 3/4 TURN AFTER THE O-RING CONTACTS THE BASE.




POWER TAKE OFF SYSTEM

POWER TAKE OFF ADAPTER

A power take off adapter can be attached to the generator backend. This adapter allows access to the full power of the engine for a variety of hydraulic and electrical accessories.

The horsepower can be utilized either for AC amperage output or to operate the power take off.



Contact your WESTERBEKE DISTRIBUTOR for additional information.

LAY-UP & RECOMMISSIONING

GENERAL

Many owners rely on their boatyards to prepare their craft, including engines and generators, for lay-up during the off-season or for long periods of inactivity. Others prefer to accomplish lay-up preparation themselves.

The procedures which follow will allow you to perform your own lay-up and recommissioning, or you may use them as a check list if others do the procedures.

These procedures should afford your engine protection during a lay-up and also help familiarize you with the maintenance needs of your engine.

If you have any questions regarding lay-up procedures, call your local servicing dealer; he will be more than willing to provide assistance.

Propeller Shaft Coupling [Propulsion Engine]

The transmission and propeller half couplings should always be opened up and the bolts removed when the boat is hauled out of the water or moved from land to water, and during storage in the cradle. The flexibility of the boat often puts a severe strain on the propeller shaft or coupling or both, while the boat is taken out or put in the water. In some cases, the shaft has actually been bent by these strains. This does not apply to small boats that are hauled out of the water when not in use, unless they have been dry for a considerable period of time.

Fresh Water Cooling Circuit [Propulsion Engine]

A 50-50 solution of antifreeze and distilled water is recommended for use in the coolant system at all times. This solution may require a higher concentration of antifreeze, depending on the area's winter climate. Check the solution to make sure the antifreeze protection is adequate.

Should more antifreeze be needed, drain an appropriate amount from the engine block and add a more concentrated mixture. Operate the engine to ensure a complete circulation and mixture of the antifreeze concentration throughout the cooling system. Now recheck the antifreeze solution's strength.

Lubrication System

With the engine warm, drain all the engine oil from the oil sump. Remove and replace the oil filter and fill the sump with new oil. Use the correct grade of oil. Refer to the *ENGINE LUBRICATING OIL* pages in this manual for the oil changing procedure. Run the engine and check for proper oil pressure and make sure there are no leaks.

CAUTION: Do not leave the engine's old engine oil in the sump over the lay-up period. Lubricating oil and combustion deposits combine to produce harmful chemicals which can reduce the life of your engine's internal parts.

Fuel System [Gasoline]

Top off your fuel tanks with *unleaded* gasoline of 89 octane or higher. A fuel conditioner such as *Sta-Bil* gasoline stabilizer should be added. Change the element in your gasoline/water separator and clean the metal bowl. Re-install and make certain there are no leaks. Clean up any spilled fuel.

Fuel System [Diesel]

Top off your fuel tanks with No. 2 diesel fuel. Fuel additives such as *BioBor* and *Diesel Kleen + Cetane Boost* should be added at this time to control algae and condition the fuel. Care should be taken that the additives used are compatible with the primary fuel filter/water separator used in the system. Change the element in your primary fuel filter/water separator, if the fuel system has one, and clean the separator sediment bowl.

Change the fuel filter elements on the engine and bleed the fuel system, as needed. Start the engine and allow it to run for 5 - 10 minutes to make sure no air is left in the fuel system. Check for any leaks that may have been created in the fuel system during this servicing, correcting them as needed. Operating the engine for 5 - 10 minutes will help allow movement of the treated fuel through the injection equipment on the engine.

Raw Water Cooling Circuit

Close the through-hull seacock. Remove the raw water intake hose from the seacock. Place the end of this hose into a five gallon bucket of clean fresh water. Before starting the engine, check the zinc anode found in the primary heat exchanger on the engine and clean or replace it as required, and also clean any zinc debris from inside the heat exchanger where the zinc anode is located. Clean the raw water strainer.

Start the engine and allow the raw water pump to draw the fresh water through the system. When the bucket is empty, stop the engine and refill the bucket with an antifreeze solution slightly stronger than needed for winter freeze protection in your area.

Start the engine and allow all of this mixture to be drawn through the raw water system. Once the bucket is empty, stop the engine. This antifreeze mixture should protect the raw water circuit from freezing during the winter lay-up, as well as providing corrosion protection.

Remove the impeller from your raw water pump (some antifreeze mixture will accompany it, so catch it in a bucket). Examine the impeller. Acquire a replacement, if needed, and a cover gasket. Do not replace the impeller (into the pump) until recommissioning, but replace the cover and gasket.

Intake Manifold and Thru-Hull Exhaust

Place a clean cloth, lightly soaked in lubricating oil, in the opening of the intake manifold to block the opening. Do not shove the cloth out of sight. (If it is not visible at recommissioning, and an attempt is made to start the engine, you may need assistance of the servicing dealer. Make a note to remove the cloth prior to start-up. The thru-hull exhaust port can be blocked in the same manner.

LAY-UP & RECOMMISSIONING

Starter Motor

Lubrication and cleaning of the starter drive pinion is advisable, if access to the starter permits its easy removal. Make sure the battery connections are shut off before attempting to remove the starter. Take care in properly replacing any electrical connections removed from the starter.

Cylinder Lubrication [Diesel]

If you anticipate a long lay-up period (12 months or more) WESTERBEKE recommends removal of the glow plugs for access to the cylinders. Squirt some Marvel Mystery Oil into the cylinder walls. Rotate the engine crankshaft by hand two revolutions and re-install the glow plugs.

If your engine does not have glow plugs, the injectors will have to be removed. Be sure to have replacement sealing washers for the injectors and return fuel line as needed.

Intake Manifold [Gasoline]

Clean the filter screen in the flame arrester, and place a clean cloth lightly soaked in lube oil around the flame arrester to block any opening. Also place an oil-soaked cloth in the through-hull exhaust port. Make a note to remove cloths prior to start-up!

Cylinder Lubrication [Gasoline]

After engine shutdown, remove the spark plugs and spray a small amount of fogging oil into each cylinder. Rotate the crankshaft manually two complete revolutions. Re-install the spark plugs loosely for winter lay-up

NOTE: At spring commissioning, remove the plugs and rotate the crankshaft two full revolutions. Re-install the spark plugs, tighten properly and connect the high tension leads fully onto each spark plug.

Batteries

If batteries are to be left on board during the lay-up period, make sure that they are fully charged, and will remain that way, to prevent them from freezing. If there is any doubt that the batteries will not remain fully charged, or that they will be subjected to severe environmental conditions, remove the batteries and store them in a warmer, more compatible environment.

WARNING: Lead acid batteries emit hydrogen, a highly-explosive gas, which can be ignited by electrical arcing or a lighted cigarette, cigar, or pipe. Do not smoke or allow an open flame near the battery being serviced. Shut off all electrical equipment in the vicinity to prevent electrical arcing during servicing.

Transmission [Propulsion Engine]

Check or change the fluid in the transmission as required. Wipe off grime and grease and touch up any unpainted areas. Protect the coupling and the output flange with an anti-corrosion coating. Check that the transmission vent is open. For additional information, refer to the TRANSMISSION SECTION.

Spare Parts

Lay-up time provides a good opportunity to inspect your Westerbeke engine to see if external items such as drive belts or coolant hoses need replacement. Check your basic spares kit and order items not on hand, or replace those items used during the lay-up, such as filters and zinc anodes. Refer to the SPARE PARTS section of this manual.

Recommissioning

The recommissioning of your Westerbeke engine after a seasonal lay-up generally follows the same procedures as those described in the PREPARATIONS FOR STARTING section regarding preparation for starting and normal starts. However, some of the lay-up procedures will need to be counteracted before starting the engine.

1. Remove the oil-soaked cloths from the intake manifold.
2. Remove the raw water pump cover and gasket and discard the old gasket. Install the raw water pump impeller removed during lay-up (or a replacement, if required). Install the raw water pump cover with a new cover gasket.
3. Reinstall the batteries that were removed during the lay-up, and reconnect the battery cables, making sure the terminals are clean and that the connections are tight. Check to make sure that the batteries are fully charged.


CAUTION: Wear rubber gloves, a rubber apron, and eye protection when servicing batteries. Lead acid batteries emit hydrogen, a highly explosive gas, which can be ignited by electrical arcing or a lighted cigarette, cigar, or pipe. Do not smoke or allow an open flame near the battery being serviced. Shut off all electrical equipment in the vicinity to prevent electrical arcing during servicing.

4. Remove the spark plugs, wipe clean, re-gap, and install to proper tightness [gasoline].
5. Check the condition of the zinc anode in the raw water circuit and clean or replace the anode as needed. Note that it is not necessary to flush the antifreeze/fresh water solution from the raw water coolant system. When the engine is put into operation, the system will self-flush in a short period of time with no adverse affects. It is advisable, as either an end of season or recommissioning service, to inspect the area where the zinc is located in the heat exchanger and clear any and all zinc debris from that area.
6. Start the engine in accordance with procedures described in the PREPARATIONS FOR STARTING section of this manual.

SUGGESTED SPARE PARTS

WESTERBEKE MARINE DIESEL GENERATORS

CONTACT YOUR WESTERBEKE DEALER FOR SUGGESTIONS AND ADDITIONAL INFORMATION




WESTERBEKE RECOMMENDS CARRYING ENOUGH SPARE ENGINE OIL (YOUR BRAND) FOR AN OIL CHANGE (5 QTS.) AND A GALLON OF PREMIXED COOLANT.

SPARE PARTS KITS

WESTERBEKE also offers two Spare Parts Kits, each packaged in a rugged hinged toolbox. Kit "A" includes the basic spares. Kit "B" is for more extensive off-shore cruising.

A Kit

- Impeller Kit
- Heat Exchanger Gasket
- Fuel Filter with Gasket
- Oil Filter
- Drive Belt
- Zinc Anodes



B Kit

- Impeller Kit
- Water Pump Repair Kit
- Thermostat Kit
- Zinc Anodes
- Complete Gasket Kit
- Heat Exchanger Gasket
- Injector
- Fuel Filter with Gasket
- Oil Filter
- Drive Belt

WESTERBEKE
Engines & Generators

